Dear VIZIO Customer,

Congratulations on your new VIZIO M320NV or M370NV television purchase. To get the most out of your new VIZIO HDTV, read these instructions before making any adjustments, and retain them for future reference. We hope you will experience many years of enjoyment from your new VIZIO HDTV High Definition Television.

For assistance, call **877-MYVIZIO** (877-698-4946) or e-mail us at www.VIZIO.com.

To purchase or inquire about accessories and installation services for your VIZIO HDTV, visit our website at www.VIZIO.com or call toll free at **888-849-4623.**

We recommend you register your VIZIO HDTV either at our website www.VIZIO.com or fill out and mail your registration card. For peace of mind and to protect your investment beyond the standard warranty, VIZIO offers on-site extended warranty service plans. These plans give additional coverage during the standard warranty period. Visit our website or call us to purchase a plan.

Write down the serial number located on the back of your HDTV for easy reference when obtaining warranty support:

Serial #: _____ Purchase Date _____

HDMI logo and "High Definition Multimedia Interface" are registered trademarks of HDMI Licensing LLC.

Manufactured under license from Dolby Laboratories.

Dolby and the double-D symbol are trademarks of Dolby Laboratories.

TruSurround HD *and* TruVolume *are trademarks of SRS Labs, Inc.*

TruSurround HD and TruVolume technologies are incorporated under license from SRS Labs, Inc.

This product qualifies for ENERGY STAR in the "factory default (Home Use)" setting and this is the setting in which power savings will be achieved. Changing the factory default picture setting or enabling other features will increase power consumption that could exceed the limits necessary to qualify for Energy Star rating.

© 2010. All rights reserved. The V, VIZIO, VIZIO XVT, VIZIO VIA, TruLED, 240Hz SPS, Slim Line, Smooth Motion, Where Vision Meets Value names, phrase and symbols are trademarks or registered trademarks of VIZIO, Inc. All other trademarks are of their respective owners. Contents subject to change without notice.

Important Safety Instructions

Your HDTV is designed and manufactured to operate within defined design limits. Misuse may result in electric shock or fire. To prevent your HDTV from being damaged, the following rules should be observed for the installation, use, and maintenance of your HDTV. Read the following safety instructions before operating your HDTV. Keep these instructions in a safe place for future reference.

- To reduce the risk of electric shock or component damage, switch off the power before connecting other components to your HDTV.
- Unplug the power cord before cleaning your HDTV. A damp cloth is sufficient for cleaning your HDTV. Do not use a liquid or a spray cleaner for cleaning your HDTV. Do not use abrasive cleaners.
- Always use the accessories recommended by the manufacturer to insure compatibility.
- When moving your HDTV from an area of low temperature to an area of high temperature, condensation may form in the housing. Wait before turning on your HDTV to avoid causing fire, electric shock, or component damage.

- Use only with the cart, stand, tripod, bracket, or table specified by manufacturer or sold with your HDTV. When a cart is used, use caution when moving the cart/HDTV combination to avoid injury from tip-over. Do not place your HDTV on an unstable cart, stand, or table. If your HDTV falls, it can injure a person and cause serious damage to your HDTV. Use only a cart or stand recommended by the manufacturer or sold with your HDTV.
- A distance of at least three feet should be maintained between your HDTV and any heat source, such as a radiator, heater, oven, amplifier etc. Do not install your HDTV close to smoke. Operating your HDTV close to smoke or moisture may cause fire or electric shock.
- Slots and openings in the back and bottom of the cabinet are provided for ventilation. To ensure reliable operation of your HDTV and to protect it from overheating, be sure these openings are not blocked or covered. Do not place your HDTV in a bookcase or cabinet unless proper ventilation is provided.
- Never push any object into the slots and openings on your HDTV cabinet. Do not place any objects on the top of your HDTV. Doing so could short circuit parts causing a fire or electric shock. Never spill liquids on your HDTV.
- Your HDTV should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.
- Do not apply pressure or throw objects at your HDTV. This may compromise the integrity of the display. The manufacturer's warranty does not cover user abuse or improper installations.
- The power cord must be replaced when using different voltage than the voltage specified. For more information, contact your dealer.
- Your HDTV is equipped with a **three-pronged grounded plug (a plug with a third grounding pin)**. This plug will fit only into a grounded power outlet. This is a safety feature. If your outlet does not accommodate the three-pronged, have an electrician install the correct outlet, or use an adapter to ground your HDTV safely. **Do not defeat the safety purpose of the grounded plug.**
- When connected to a power outlet, power is always flowing into your HDTV. To totally disconnect power, unplug the power cord.

- The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of un-isolated, dangerous voltage within the inside of your HDTV that may be of sufficient magnitude to constitute a risk of electric shock to persons.

- The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and servicing instructions in the literature accompanying your HDTV.

- Do not overload power strips and extension cords. Overloading can result in fire or electric shock.
- The wall socket should be installed near your HDTV and easily accessible.
- Only power of the marked voltage can be used for your HDTV. Any other voltage than the specified voltage may cause fire or electric shock
- Do not touch the power cord during lightning. To avoid electric shock, avoid handling the power cord during electrical storms.
- Unplug your HDTV during a lightning storm or when it will not be used for long period of time. This will protect your HDTV from damage due to power surges.
- Do not attempt to repair or service your HDTV yourself. Opening or removing the back cover may expose you to high voltages, electric shock, and other hazards. If repair is required, contact your dealer and refer all servicing to qualified service personnel.
- Keep your HDTV away from moisture. Do not expose your HDTV to rain or moisture. If water penetrates into your HDTV, unplug the power cord and contact your dealer. Continuous use in this case may result in fire or electric shock.
- Do not use your HDTV if any abnormality occurs. If any smoke or odor becomes apparent, unplug the power cord and contact your dealer immediately. Do not try to repair your HDTV yourself.
- Avoid using dropped or damaged appliances. If your HDTV is dropped and the housing is damaged, the internal components may function abnormally. Unplug the power cord immediately and contact your dealer for repair. Continued use of your HDTV may cause fire or electric shock.
- Do not install your HDTV in an area with heavy dust or high humidity. Operating your HDTV in environments with heavy dust or high humidity may cause fire or electric shock.
- Follow instructions for moving your HDTV. Ensure that the power cord and any other cables are unplugged before moving your HDTV.
- When unplugging your HDTV, hold the power plug, not the cord. Pulling on the power cord may damage the wires inside the cord and cause fire or electric shock. When your HDTV will not be used for an extended period of time, unplug the power cord.
- To reduce risk of electric shock, do not touch the connector with wet hands.
- Insert batteries in accordance with instructions. Incorrect polarities may cause the batteries to leak which can damage the remote control or injure the operator.
- If any of the following occurs, contact the dealer:
    - The power cord fails or frays.
    - Liquid sprays or any object drops into your HDTV.
    - Your HDTV is exposed to rain or other moisture.
    - Your HDTV is dropped or damaged in any way.
    - The performance of your HDTV changes substantially.

Television Antenna Connection Protection

External Television Antenna Grounding

If an outside antenna/satellite dish or cable system is to be connected to the TV, make sure that the antenna or cable system is electrically grounded to provide some protection against voltage surges and static charges.

Article 810 of the National Electrical Code, ANSI/NFPSA 70, provides information with regard to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of the grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements of the grounding electrode.

Lightning Protection

For added protection of the TV during a lightning storm or when it is left unattended or unused for long periods of time, unplug the TV from the wall outlet and disconnect the antenna or cable system.

Power Lines

Do not locate the antenna near overhead light or power circuits, or where it could fall into such power lines or circuits.


GROUND CLAMP
ANTENNA LEAD IN WIRE
ANTENNA DISCHARGE UNIT (NEC SECTION 810-20)
GROUNDING CONDUCTORS (NEC SECTION 810-21)
GROUND CLAMPS
ELECTRIC SERVICE EQUIPMENT
POWER SERVICE GROUNDING ELECTRODE SYSTEM (NEC ART 250, PART H)

Remember, the screen of the coaxial cable is intended to be connected to earth in the building installation.

Advisory of the DTV Transition

The nationwide switch to digital television broadcasting will be complete on June 12, 2009, but your local television stations may switch sooner. After the switch, analog-only television sets that receive TV programming through an antenna will need a converter box to continue to receive over-the-air TV. Watch your local stations to find out when they will turn off their analog signal and switch to digital-only broadcasting. Analog-only TVs should continue to work as before to receive low power, Class A or translator television stations and with cable and satellite TV services, gaming consoles, VCRs, DVD players, and similar products.

For additional information, contact the parties listed below, as appropriate:

FCC (US Federal Communications Commission)
http://www.fcc.gov/
Phone: 1-888-CALL-FCC (1-888-225-5322)
TTY: 1-888-TELL-FCC (1-888-835-5322)
Fax: 1-866-418-0232
E-mail: fccinfo@fcc.gov

NTIA (National Telecommunications and Information Administration)
http://www.ntia.doc.gov/
1-888-DTV-2009

Listings of US Television Stations
http://www.high-techproductions.com/usTVstations.htm

Note: Your VIZIO HDTV is capable of receiving Digital Broadcasts, and no Digital Converter Box is required.

Table of Contents

Important Safety Instructions 2
Television Antenna Connection Protection 4
Advisory of the DTV Transition 5

CHAPTER 1 SETTING UP YOUR HDTV 10

Finding a Location for Your HDTV 10
Attaching the TV Stand 10
Wall Mounting your HDTV 11

CHAPTER 2 BASIC CONTROLS AND CONNECTIONS 12

Front Panel 12
Jag Wheel Control 12
Side Panel Connections 13
Rear Panel Connections 13

CHAPTER 3 VIZIO REMOTE CONTROL 14

Installing the Batteries 14
Remote Control Range 14
VIZIO Remote Control Precautions 14
Remote Control Buttons 15

CHAPTER 4 GETTING STARTED 16

CHAPTER 5 USING YOUR HDTV FOR THE FIRST TIME 17

Select an Input Source 17
Watching a TV Program 17
Viewing Digital TV Program Information 18

CHAPTER 6 CONNECTING EQUIPMENT 19

Which Video Connection Should I Use? 19
Connecting Your Cable or Satellite Box 20
Using HDMI (Best) 20
HDMI Connections for Cable or Satellite Boxes with DVI 20
Using Component Video (Better) 21
Using Composite Video (Good) 21
Using Coaxial (Antenna) (Good) 21
Connecting Your DVD Player 22
Using HDMI (Best) 22
HDMI Connections for DVD Players with DVI 22
Using Component Video (Better) 23
Using Composite (AV) Video (Good) 23
Connecting Coaxial (RF) 24
Using Your Antenna or Digital Cable for Standard or Digital TV 24
Connecting Your VCR or Video Camera 24
Connecting a Home Theater System 25
Using RCA 25
Connecting the cables 25
Turning TV speakers off 25
Using Optical (S/PDIF) 25
Connecting a Computer 26
RGB (VGA) 26
Using HDMI 26

CHAPTER 7 VIEWING PICTURES 27

Viewing Pictures 27
Adjusting Photo Settings 27
Adjusting Photo Settings 28
Slideshow Mode 28
Repeat 28
Sort By 28
Duration 28
Slideshow Effect 28
Thumbnail Size 28
Info 28

CHAPTER 8 ADJUSTING YOUR HDTV SETTINGS 29

Using the On-screen Display (OSD) 29
Input Menu 29
Wide Menu 30
Normal 30
Wide 30
Panoramic 30
Stretch 30
CC (Closed Caption) Menu 31
Analog Closed Caption 31
Digital Closed Caption 31
Digital CC Style 31
Sleep Timer Menu 31
Picture Menu 31
Picture Mode 31
Backlight 31
Brightness 32
Contrast 32
Color 32
Tint 32
Sharpness 32
More 32
Audio Menu 34
Audio Mode 34
Balance 34
Lip Sync 34
TV Speakers 34
Advanced Audio 34
Equalizer Settings 35
Reset Audio Mode 35
Settings Menu 35
Tuner 35
Name Input 36
Parental Controls 37
Menu Language 39
Time & Local Settings 39
CEC 39
Media Menu 40
Slideshow Mode 40
Repeat 40
Sort By 40
Duration 40

Slideshow Effect 40
Thumbnail Size 40
Info 40
Help Menu 41
System Info 41
Reset TV Settings 41
Clear Memory (Factory Default) 41
Start Setup Wizard 41

CHAPTER 9 PROGRAMMING THE VIZIO UNIVERSAL REMOTE CONTROL 42

Using a Cable or Satellite Box Remote 42
Programming other devices 42
Programming your Blu-Ray or DVD Player 42
Programming your Home Theater System 42
Programming your Cable or Satellite Set-Top Box 43
Searching for Device Codes 43
Reset Remote Control to Factory Settings 43
Remote Control Codes 44
Television Codes 44
Satellite Receiver Codes 51
PVR Codes 52
DVD Player Codes 52
Amplifier / Receiver / Tuner Codes 54
Audio Accessory Codes 56
VCR Codes 56

CHAPTER 10 MAINTENANCE AND TROUBLESHOOTING 58

Cleaning the TV and Remote Control 58
Troubleshooting Guide 58
Telephone & Technical Support 61
Compliance 61
FCC Class B Radio Interference Statement 61

CHAPTER 11 SPECIFICATIONS 62

Preset PC Resolutions 65
Resolution through RGB Input 65

WARRANTY 66

INDEX 67

Opening the Package

Your HDTV and its accompanying accessories are carefully packed in a cardboard carton that has been designed to protect it from transportation damage. After you have opened the carton, check that your HDTV is in good condition and that all of the contents are included.

The glass surface can easily be scratched or broken, so handle your HDTV gently and never place your HDTV with the glass facing downwards on a surface without protective padding.

IMPORTANT: Save the carton and packing material for future shipping.

Package Contents

- VIZIO M320NV or M370NV
- VIZIO remote control VUR12
- AAA batteries for the remote control (2)
- Power cord
- Detachable base with thumbscrew
- Cleaning cloth
- This user manual
- Quick Setup Guide
- Registration Card

HDTV Accessories and Services

Additional certified accessories for your HDTV are sold separately, including:

- Wall mounts
- High Definition cables
- Extra or replacement remote controls
- Sound Bars
- Blu-ray DVD Players

VIZIO also offers installation services and extended warranty services for your HDTV.

To purchase or inquire about additional accessories and services for your VIZIO HDTV, visit our website at www.VIZIO.com or call us toll free at **877-MYVIZIO** (877-698-4946).

Caution: Do not apply pressure or throw objects at your HDTV (including game controllers).
This may compromise the integrity of the display. The manufacturer's warranty does not cover user abuse or improper installations.

Chapter 1 Setting Up Your HDTV

Finding a Location for Your HDTV

Here are some things you should consider when deciding on a proper location for your HDTV:

- The power consumption of your HDTV is about 57.1W (M320NV) and 56W (M370NV) (AVG
- Use the included power cord.
- When an extension cord is required, use one with the correct power rating. The 3-pronged cord must be grounded and the grounding feature (3rd prong) must not be compromised.
- Install your HDTV on a flat surface to avoid tipping.
- For proper ventilation, you must allow space between the back of your HDTV and the wall.
- Avoid installing your HDTV in places with high humidity, dust, or smoke so you do not shorten the service life of the electronic components.
- Install your HDTV in a level, landscape orientation, with the VIZIO logo at the bottom to prevent poor ventilation and excessive component damage.
- If you want to mount your HDTV on the wall, see below for additional information.
- Read this user manual carefully before installing your HDTV.

VIZIO offers professional installation services including home networking. Contact VIZIO for more information on these services at **877-MYVIZIO** (877-698-4946) or www.VIZIO.com.

Attaching the TV Stand

Note: We strongly recommend that two people perform the setup and assembly due to the weight and size of the TV.

Unpack the TV and stand base:

1. Remove the two top foam end caps.
2. Remove the stand base and accessory box from packaging.
3. Remove the TV from the box and lay it face down on a clean, padded, flat surface.

Note: Make sure that the surface is free of debris to prevent the TV screen from getting scratched.

Attach the TV stand base:

1. Align the stand base to the back of the TV.
2. Insert the four screws provided and tighten.

Wall Mounting your HDTV

Your HDTV can be mounted on the wall for viewing. If you choose to mount your HDTV on the wall, follow the instructions below.

1. Write down the serial number located on the back of your HDTV in the space provided on page 1 to have it handy if you need to call for support.
2. Remove the stand base and neck:
    a. Disconnect the cables from your HDTV.
    b. Place your HDTV face down on a soft, flat surface to prevent damage to the screen.
    c. Remove the four (4) screws holding the stand neck, and then remove the neck and base.

Note: To remove the base from the neck, unscrew thumbscrew on bottom.

1. Mount your HDTV on the wall:
    a. Attach your HDTV to a wall mount (sold separately) using the mounting holes in the back panel of your HDTV.
    b. Read the instructions that came with your specific wall mount to properly hang your HDTV.

Wall Mounting Specifications	
Screw Size	M4
Screw Length	18.0 mm
Screw Pitch	1.0 mm
Hole Pattern	VESA standard 100 x 100 mm spacing

Chapter 2 Basic Controls and Connections

Front Panel

1. **Remote Control Sensor**—Point the remote control directly at this window on the lower left corner of your HDTV for the best response to the remote signal.
2. **POWER 'VIZIO' LIGHT—**The VIZIO name lights white when powered on and orange when powered off.

Jag Wheel Control

The Jag wheel on the side of your HDTV performs all of the same functions you might see as buttons on other TVs, including volume, power, and channel change. All of these functions have been combined into a single wheel on your M320NV or M370NV.

- Press the Jag wheel once to turn your HDTV on.
- Press and hold the Jag wheel for three seconds to turn your HDTV off.
- When watching TV, scroll the Jag wheel up and down to turn the volume up and down.
- To open the Quick Menu, press the Jag wheel for two seconds, scroll the wheel up and down to highlight an option, and then press in the wheel again to confirm your selection. If you do not press anything, the menu will automatically close after 10 seconds.

- **Volume**—Press to increase or decrease the speaker volume.
- **Channel**—Press to open a channel list. Choose the channel with the wheel and then press the wheel to go to that channel.
- **Input Source**—Press to cycle through the various devices connected to your TV (called Inputs). The inputs cycle in the following sequence: TV, AV, Comp, HDMI-1, HDMI-2, HDMI SIDE, RGB, and Media. After you have stepped through the entire sequence, you will return to the beginning.



- **Exit**—Press to close the Quick Menu.
- **Power Off**—Press to turn your HDTV off.

Note: The Jag wheel does not operate in the OSD menu. Please use your remote control to change your HDTV settings.

Side Panel Connections



1. **USB**:
   - Insert a FAT/FAT32 formatted USB drive to view pictures.
   - Service port for use by a professional service technician.
2. **HDMI SIDE**—Connect digital video devices such as a DVD player or Set-Top Box through this all digital connector. There are additional HDMI connectors on the back.

Rear Panel Connections



1. **HDMI 1 and 2 —**Connect digital video devices such as a DVD player or Set-Top Box through this all digital connector. There is an additional HDMI connector on the side.
2. **AV—**Connect Composite video devices, such as a VCR or game console. Use the white and red connectors to connect the external audio from the same source.
3. **COMPONENT (Y Pb/Cb Pr/Cr with L/R Audio)—**Connect Component video devices such as a DVD Player or Set Top Box here.
4. **AUDIO OUT**:
5. **OPTICAL**—When digital TV is selected for viewing, the audio associated with the programming will be available on the S/PDIF Optical connector for connection to a VIZIO Sound Bar or your Home Theater system.
6. **ANALOG L/R**—Connect the audio from the HDTV to an external device, such as a Home Theater System, external amplifier, or stereo. Speakers cannot be connected directly here.
7. **DTV/TV—** Connect to an antenna or digital cable source. For digital TV stations in your area visit www.antennaweb.org. For Cable and Satellite Set Top Boxes, we recommend that you use a HDMI or Component cable connection for high definition image quality.
8. **RGB PC—**Connect the video and audio from a computer here. Connect a 1/8” mini plug stereo connector from the computer to the TV if you want the sound to come from the HDTV speakers.

Chapter 3 VIZIO Remote Control

Installing the Batteries

1. Remove the battery cover.
2. Insert two AAA batteries into the remote control. Make sure that you match the (+) and (-) symbols on the batteries with the (+) and (-) symbols inside the battery compartment.
3. Replace the battery cover.

Precautionary Tips for Inserting the Batteries:

- Only use AAA batteries.
- Do not mix new and old batteries. This may result in cracking or leakage that may cause a fire or lead to personal injury.
- Inserting the batteries incorrectly may also result in cracking or leakage that may cause a fire or lead to personal injury.
- Dispose of batteries according to local hazardous waste regulations.
- Keep the batteries away from children and pets.

Remote Control Range

- Point the remote control directly at this sensor for the best response to the remote signal.
- Do not place any obstacles between the remote control and the remote control sensor.
- The effective range of the remote control is approximately 22 feet (7 meters) from the front of the remote control sensor, 30° to the left and right, 20° up and down.

VIZIO Remote Control Precautions

- The remote control should be kept dry and away from heat sources. Avoid humidity.
- If the TV responds erratically to the remote control or does not respond at all, check the batteries. If the batteries are low or exhausted, replace them with fresh batteries.
- When not using the remote control for a long period of time, remove the batteries.
- Do not take the batteries apart, heat them, or throw them into a fire.
- Do not subject the remote control to undue physical stress, such as striking or dropping it.
- Do not attempt to clean the remote control with a volatile solvent. Wipe it with a clean, damp cloth.

Remote Control Buttons

POWER (**)**—Press to turn the TV on from the Standby mode. Press it again to return to the Standby mode.

Device Buttons:

- **DVD**—Press to select a DVD player that has been programmed to work with this remote.
- **AUDIO**—Press to select a Home Theater System or Audio Amplifier that has been programmed to work with this remote.
- **CABLE**—Press to select a Cable or Satellite Set Top Box that has been programmed to work with this remote.
- **TV**—Press to return to TV mode. If the remote is not working, press this button to return the functions back to TV.

CEC-Supported Buttons:

CEC needs to be set up and enabled for these buttons to work. See *CEC* on page 39 for more information.

● (Record)—Press to begin recording on your CEC-supported device.

❚❚ (Pause)—Press to pause playback on your CEC-supported device.

► (Play)—Press to start Playback on your CEC-supported device.

■ (Stop)—Press to stop playback/recording on your CEC-supported device.

⏮ (Previous)—Press to skip the previous track on your CEC-supported device.

◄◄ (Reverse)—Press to reverses playback on your CEC-supported device.

►► (Fast Forward)—Press to fast forward playback on your CEC-supported device.

⏭ (Next)—Press to skip to the next chapter on your CEC-supported device.

EXIT—Press to exit from open menus.

MENU—Press to open the On-Screen Display (OSD) menu.

OK—Press this button to display the Channel List. Press to confirm selections for On-Screen Display (OSD) menus.

▲▼◄ ►—Press to navigate the OSD menu. They will also be used as value settings when the slide bar is shown on the screen and option settings to turn a feature off or on.

BACK—Press to return to a previous OSD menu. Press repeatedly to close the OSD.

GUIDE—Press to display detailed program information when viewing a digital TV program.

Color Buttons (Yellow, Blue, Red, & Green):

- **Yellow**—Press to perform the same function as the “A” button on your Cable or Satellite box when using the remote to control your pre-programmed Cable/Satellite Box DVR.
- **Blue**—Press to perform the same function as the “B” button on your Cable or Satellite box when using the remote to control your pre-programmed Cable/Satellite Box DVR.
- **Red**—Press to perform the same function as the “C” button on your Cable or Satellite box when using the remote to control your pre-programmed Cable/Satellite Box DVR.
- **Green**—Press to perform the same function as the “D” button on your Cable or Satellite box when using the remote to control your pre-programmed Cable/Satellite Box DVR.

VOL +/- —Press to turn the volume up or down.

MEDIA – Use this button to access the USB drive to view your pictures.

MUTE—Press to turn the sound on and off.

LAST— Press to recall the previously viewed channel.

CH +/- —Press to change the channels up or down

HDMI—Press to select the HDMI input. Press repeatedly to cycle between both HDMI inputs.

AV—Press to select the AV input.

TV—Press to select the TV input.

Number Button Pad—Press to select a channel or enter a password.

INPUT—Press to cycle through the various devices connected to your TV (called Inputs). The inputs cycle in the following sequence: TV, AV, Comp, HDMI-1, HDMI-2, HDMI SIDE, RGB, and Media. After you have stepped through the entire sequence, you will return to the beginning.

- (DASH)—Press to insert a dash between the main and sub-channels. For example, channel 28-2 would be selected by the button sequence 2, 8, DASH, 2.



Chapter 4 Getting Started

Your HDTV has a built-in setup App that runs when you turn on your TV for the first time. Follow the on-screen directions to easily setup your new HDTV.

1. Insert the batteries into the remote control.
2. Connect the power cord to the power cord connector on the back of your HDTV, and then plug the power cord into an AC wall socket.
3. Connect your devices to your HDTV (see Connecting Equipment on page 19 for detailed steps).
4. Turn on your TV. The Setup App will automatically play and guide your thru the initial setup of your HDTV. Use the arrow and OK buttons to navigate through the Setup App. During the setup process you will:
    - Choose your Menu language
    - Set the TV to Home Mode for the best picture and most efficient energy usage.
    - Set your Time Zone and Daylight Savings preferences
    - Add your TV channels (unless you have a Cable/Satellite Set-Top Box)



Chapter 5 Using your HDTV for the first time

Select an Input Source

1. Select the input source for your HDTV by pressing the **INPUT** button on the remote control or the front of your TV. Pressing this button will cycle you through the following options: TV, AV, Comp, HDMI-1, HDMI-2, RGB, and Media.
2. Turn on your device and you will see a picture on your HDTV. If there is no picture, make sure you have selected the correct input on your HDTV.

Note: If the selected device is RF connected, your HDTV needs to be in **TV** mode and on either channel 3 or channel 4 matching the channel which has been selected on the back of the VCR, Cable Box, External TV Tuner or Satellite Receiver. Refer to Owner or User's Manual of such equipment for details.

Watching a TV Program

Before you start watching TV, make sure that any cable, satellite or off-air antenna connections are secure. Also, verify that the AC/DC power adapter is plugged into a correctly grounded electrical outlet or surge protector.

1. Press the power button on the remote control. The VIZIO logo on the front will light up white.
2. Select the input to which your device is connected that provides TV programming (i.e. TV, HDMI, COMP).

Note: You should be able to see a picture. If you do not, make sure that all of your HDTV connections are secure and you have selected the correct video input source. Each press of the **INPUT** button on the remote control will cycle through the available inputs. Press the button until the input associated with the device you want to view is shown.

3. When using the TV input, press the channel buttons on the remote control or the TV to change the channel. The channel buttons will not work if you are watching a program using HDMI, Component, or AV inputs.

Viewing Digital TV Program Information

When the channel is changed or when you press the **GUIDE** button, an information header is shown over the picture for a few seconds. Each press of the **GUIDE** button will display more information about the program:

Time Warp: Mouse Trap
Ch 50-123
KCAL DTV
CABLE
11:00 AM - 12:00 AM
TV-PG (V)
CC-OFF
ENGLISH
DOLBY 5.1
720p HD
In this hour-long special, the Time Warp team runs off to join the circus with trap-testing Rev. Tommy Gunn and with high-flying Cirque du Soleil, explore their inner stuntmen, and put everything but wood in a chipper.


Sunday , 26 November 2009 10:30:32 PM
VIZIO
4-10
20-1 KBWB-HD
20-2
Tomorrow 3:30 PM Project Runway
Tomorrow 4:30 PM American Next Top Model
Tomorrow 5:30 PM 500 Days of Summer
Tomorrow 8:00 PM Soul Train
Tomorrow 8:30 PM Sponge Bob Square Pants- Jellyfish Catching
CC
3:00 AM - 3:30 AM Mon, 27-Jun
Not Rated
Project Runway is an American reality television series on Lifetime Television, previously on the Bravo network, which focuses on fashion design and is hosted by model Heidi Klum. The contestants compete with each other to create the best clothes and are usually restricted in time, materials, and theme. Their designs are judged and one or more designers are eliminated each week.

Chapter 6 Connecting Equipment

Which Video Connection Should I Use?

You have six options for connecting your video equipment box to your HDTV from a basic connection to the most advanced for digital displays. Based on your Home Theater configuration, you can decide which option is the right one for you.

Connection Quality (type)	Connector	Description
Best (digital)		**HDMI** delivers the best image quality of any of the cable types available and it's all done over one cable. You get a great picture and cut down on your cable clutter. HDMI provides digital quality and amazing sound so if your TV has HDMI, this is the connection type you should be using.
Best (digital) - - - - - - - - - - - Good (analog)		Connect your **antenna** or **coaxial** cable to watch TV programming. This cable usually comes from your cable box or right out of the wall.
Best (analog)		The **RGB (VGA)** port allows you to connect your computer so you can use the TV as your monitor.
Better (analog)		**Component** consists of three cables for transmitting video and two cables for transmitting audio: one red and one white. Component video provides a sharper image than Composite video and should be used instead of composite when possible. However, because it is still an analog connection, it won't provide the high-quality video and audio that HDMI can produce.
Good (analog)		**Composite** consists of one yellow cable for transmitting video and two cables for transmitting audio: one red and one white. It is capable of transmitting stereo sound and standard definition video (480i). While it provides a good image, it has lower image quality than HDMI or Composite. So try to use one of those connections first.

Note: To maintain the display quality, use a VIZIO certified HDMI cable. This cable is available in 6, 8, and 12 foot lengths. Visit www.vizio.com or call 1-888-VIZIOCE (1-888-849-4623) for details.

Connecting Your Cable or Satellite Box

Using HDMI (Best)

Cable and Satellite Boxes that have a HDMI digital interface should be connected using HDMI for optimal results. To maintain image quality, use a VIZIO certified HDMI cable. This cable is available in 6, 15, and 30 foot lengths. Visit www.VIZIO.com or call **877-MYVIZIO** (877-698-4946) for details.

1. Turn off your HDTV and Cable/Satellite box.
2. Connect an HDMI cable to the HDMI output of your Cable/Satellite box and the other end to the **HDMI 1, 2,** or **HDMI SIDE** jack on your HDTV.
3. Turn on the power to your HDTV and your Cable/Satellite box.
4. Select **HDMI-1, HDMI-2,** or **HDMI SIDE** using the **INPUT** button on the remote control or side of the TV.

Note:

- The HDMI input on your HDTV supports High-bandwidth Digital Content Protection (HDCP). HDCP encrypts the transmission between the video source and the digital display for added security and protection.
- Refer to your Cable/Satellite Set Top Box user manual for more information about the video output requirements of the product or consult your Cable or Satellite operator.

HDMI Connections for Cable or Satellite Boxes with DVI



1. Turn off your HDTV and Cable/Satellite box.
2. Using a HDMI-DVI cable, connect the DVI end to your Cable/Satellite box and the HDMI end to the **HDMI 1, 2**, or **HDMI SIDE** jack on your HDTV.
3. Turn on the power to your HDTV and your Cable/Satellite box.
4. Select **HDMI-1, HDMI-2**, or **HDMI SIDE** using the **INPUT** button on the remote control or side of the TV.

Note: There are no dedicated audio ports for HDMI so there may or may not be audio from the TV with this connection.

Using Component Video (Better)





1. Turn off your HDTV and Cable/Satellite box.
2. Connect the Component cables (green, blue, and red) from your Cable/Satellite box to the **COMPONENT** jacks on your HDTV.
3. Connect the audio cables (white and red) from your Set Top Box to the **COMPONENT L** and **R AUDIO** jacks on your HDTV.
4. Turn on your HDTV and Cable/Satellite box.
5. Select **Comp** using the **INPUT** button on the remote control or side of the TV.

Using Composite Video (Good)





1. Turn off your HDTV and Set Top Box.
2. Connect the video cable (yellow) from your Set Top Box to the **AV** jack (yellow) on your HDTV.
3. Connect the audio cables (white and red) on your Set Top Box to the **AV L** and **R AUDIO** jacks on your HDTV.
4. Turn on your HDTV and Set Top Box.
5. Select **AV** using the **INPUT** button on the remote control or side of the TV.

Using Coaxial (Antenna) (Good)



COAXIAL

1. Turn off the power to your HDTV.
2. Connect the coaxial (RF) connector from your antenna or digital cable to the **DTV/TV CABLE/ANTENNA** connector on your HDTV.
3. Turn on the power to your HDTV.
4. Select **TV** using the **INPUT** button on the remote control or side of the TV.
5. Search for new channels. See *Auto Channel Search* on page 35 for more information on scanning for channels.

Connecting Your DVD Player

Using HDMI (Best)



DVD players that have a HDMI digital interface should be connected using HDMI for optimal results. To maintain image quality, use a VIZIO certified HDMI cable. This cable is available in 6, 15, and 30 foot lengths. Visit www.VIZIO.com or call **877-MYVIZIO** (877-698-4946) for details.

1. Turn off your HDTV and DVD player.
2. Connect a HDMI cable to the HDMI output of your DVD player and the other end to the **HDMI 1, 2**, or **HDMI SIDE** jack on your HDTV.
3. Turn on the power to your HDTV and your DVD player.
4. Select **HDMI-1, HDMI-2**, or **HDMI SIDE** using the **INPUT** button on the remote control or side of the TV.

Note:

- The HDMI input on your HDTV supports High-bandwidth Digital Content Protection (HDCP). HDCP encrypts the transmission between the video source and the digital display for added security and protection.
- Refer to your DVD player user manual for more information about the video output requirements.

HDMI Connections for DVD Players with DVI



1. Turn off your HDTV and DVD player.
2. Using a HDMI-DVI cable, connect the DVI end to your DVD player and the HDMI end to the **HDMI 1, 2**, or **HDMI SIDE** jack on your HDTV.
3. Turn on the power to your HDTV and your DVD player.
4. Select **HDMI-1, HDMI-2**, or **HDMI SIDE** using the **INPUT** button on the remote control or side of the TV.

Note: There are no dedicated audio ports for HDMI so there may or may not be audio from the TV with this connection.

Using Component Video (Better)



1. Turn off the power to your HDTV and DVD player.
2. Connect the Component cable (green, blue, and red) from your DVD player to the **COMPONENT** jacks on your HDTV.
3. Connect the audio cables (white and red) from your DVD player to the **COMPONENT L** and **R AUDIO** jacks on your HDTV.
4. Turn on the power to your HDTV and DVD player.
5. Select **COMP** using the **INPUT** button on the remote control or side of the TV.

Using Composite (AV) Video (Good)



1. Turn off the power to your HDTV and DVD player.
2. Connect the Video cable (yellow) from your DVD player to the **AV** jack on your HDTV.
3. Connect the audio cables (white and red) on your DVD player to the **AV L** and **R AUDIO** jacks on your HDTV.
4. Turn on the power to your HDTV and DVD Player.
5. Select **AV** using the **INPUT** button on the remote control or side of the TV.

Connecting Coaxial (RF)

Using Your Antenna or Digital Cable for Standard or Digital TV



1. Turn off the power to your HDTV.
2. Connect the coaxial (RF) connector from your antenna or cable to the **DTV/TV CABLE/ANTENNA** connector on your HDTV.
3. Turn on the power to your HDTV.
4. Select **TV** using the **INPUT** button on the remote control or side of the TV.
5. Search for new channels. See *Auto Channel Search* on page 35 for more information on scanning for channels.

Connecting Your VCR or Video Camera





Note: Refer to your VCR or Video Camera user manual for more information about the video output requirements of the product.

1. Turn off the power to your HDTV and VCR or video camera.
2. Connect the yellow AV cable from your VCR or video camera to the **AV** jack on your HDTV.
3. Connect the audio cables on your VCR or video camera to the corresponding **L** and **R AUDIO** jacks on your HDTV.
4. Turn on the power to your HDTV and VCR or video camera.
5. Select **AV** using the **INPUT** button on the remote control or side of the TV.

Connecting a Home Theater System

Using RCA







Connecting the cables

1. Turn off the power to the HDTV and Receiver/Amp.
2. Using an audio cable (white and red connectors), connect the cable to the audio input connectors on the Receiver/Amp and connect the other end to the **AUDIO OUT** audio connectors on the back of the HDTV.
3. Turn on the power to the HDTV and Receiver/Amp.

Turning TV speakers off

1. Press **MENU** to open the OSD.
2. Press ▼ to highlight *Settings*, and then press **OK** to select.
3. Press **OK** to select *Audio*, and then press ▼ to select **TV SPEAKERS**.
4. Press ► to select **OFF** so the sound from the HDTV will be routed through your Receiver/Amp system.



Notes:

- Refer to your Receiver/Amp user manual to select the corresponding audio input.
- The audio output is not amplified and cannot be connected directly to external speakers.

Using Optical (S/PDIF)





If your sound system has a S/PDIF (optical) digital audio input you can connect it from your sound system to the **OPTICAL** digital audio out on your HDTV. This is active when receiving audio with the programs being viewed no matter what input is being used.

1. Connect one end of the optical cable to optical connectors on the Home Theater and the other end to the **OPTICAL** jack on your HDTV.
2. Turn on the power to your HDTV and home theater.
3. Change the input on your Home Theater to optical. See your Home Theater user manual for more information.

Connecting a Computer

RGB (VGA)



1. Set computer to a resolution supported by your HDTV (see *Preset PC Resolutions* on page 65). If your computer supports it, we recommend 1920x1080.
2. Turn off the power to your HDTV and computer.
3. Connect the RGB (VGA) cable from your computer to the **RGB PC** jack on of your HDTV.
4. Connect the 1/8-inch audio cable from your computer to the **RGB PC Audio** jack on your HDTV. This step is optional and only needed if you want to transmit audio from the computer through the TV.
5. Turn on the power to your HDTV and computer.
6. Select **RGB** (VGA) using the **INPUT** button on the remote control or side of the TV.

Note: Refer to your PC computer user manual for more information about the video output requirements.

Using HDMI



1. Turn off your HDTV and computer.
2. Connect a HDMI cable to the HDMI output of your computer and the other end to the **HDMI 1, 2**, or **HDMI SIDE** jack on your HDTV.
3. Connect the 1/8-inch audio cable from your computer to the **RGB PC Audio** jack on your HDTV. This step is optional and only needed if you want to transmit audio from the computer through the TV.
4. Turn on the power to your HDTV and your computer.
5. Select **HDMI-1, HDMI-2**, or **HDMI SIDE** using the **INPUT** button on the remote control or side of the TV.

Chapter 7 Viewing Pictures

Connect a USB flash drive to the USB port on your HDTV to view pictures.

- USB drives that are USB 2.0 and FAT or FAT32 are supported. The USB Port does not support external hard drives or USB hubs.
- If your USB drive is oversized and does not physically fit in the USB port, use a USB extension cable. Connect one end of the cable to your USB drive and the other end to the USB port.
- Supported file extensions include .jpg and .jpeg.

Note: Even the supported format files listed above may or may not play properly or completely, depending on the USB device, bit rate stream, and other content characteristics, as well as other factors.

Viewing Pictures

1. Insert a USB device with digital content such as photos, music, and movies into the Multimedia port on the side of your HDTV. If a USB device is already connected, press **MENU** on the remote control and select *Media*. A message will appear asking if you want to play multimedia content.
2. Press ◄ or ► to highlight **OK**, and then press **OK** to select it. The *Picture* folder will be displayed.
3. Press **OK** to select it. A menu will be displayed showing the folders and files that are on your USB device.
4. Press ◄ or ► to highlight the folder or file you want to play, and then press **OK** to select it. The file will play. See *Adjusting Photo Settings* on page 28 to adjust various settings including setting up a slideshow and setting picture duration.
5. When finished, press **EXIT** once to return to the previous screen or repeatedly to return to the main menu.



Adjusting Photo Settings

When viewing pictures you can adjust various settings, including slideshow, picture duration, etc.

1. Insert a USB device containing pictures and select the folder or files that you want to play.
2. Press **MENU**. The Picture menu will be displayed.
3. Press ▲ or ▼ on the remote control to highlight a Picture menu option, and then press ◄ or ► to adjust the setting.
4. Press **MENU** once to close the menu.

Slideshow Mode

Choose from **Shuffle, Single,** and **Sequence** to set the slideshow mode. Press **OK** to begin the slideshow. Press **OK** to stop the slideshow.

- **Single** will display one picture selected from the thumbnails for the interval set in the *Duration* option and return to the thumbnails. If the **Repeat** option is set to **On**, the selected picture will be displayed until you press **EXIT**.
- **Sequence** will show your pictures in the order they are listed on your USB device until you stop the slideshow.
- **Shuffle** will show your pictures in random order until you stop the slideshow.



Repeat

Choose from **On** or **Off** to repeat the slideshow.

Sort By

You can choose to sort the pictures on the USB device by **Photo Date**, **File Date**, or alphabetically (**File A-Z**).

Duration

Set the amount of time the picture will remain on the screen during the slideshow. Choose a time between 5 seconds and 32 seconds.

Slideshow Effect

Choose from **Random, Dissolve, Wipe Right, Wipe Left, Wipe Up, Wipe Down, Box In,** or **Box Out** to set the transition type when changing from one picture to another during a slideshow.

Thumbnail Size

Set the size of the preview pictures (thumbnails) in the menu. Choose from **Small, Medium,** or **Large.**

Info

When set to **On**, information about the picture briefly appears on your HDTV.

Chapter 8 Adjusting Your HDTV Settings

Using the On-screen Display (OSD)

The remote control or the control buttons on the side of the TV can control all the function settings. The *OSD* allows you to adjust contrast, brightness and other settings. The TV will save changes made to the settings, even if the TV is turned off.

The OSD consists of several menu options. The main menu options may vary depending on your selected input source.

Note: Some of the main menu options may have additional submenus, for example, the TV Rating submenu for Parental Controls.

1. Press **MENU**. The *OSD* opens.
2. Press ◄, ►, ▲, or ▼ on the remote control to select one of the menu options:
   - Input
   - Wide
   - CC
   - Sleep Timer
   - Picture
   - Audio
   - Settings
   - Media
   - Help
3. Press **OK** to select the option or feature you want to adjust.
4. After the menu option is displayed, press ▲ or ▼ on the remote control to select one of the items to adjust.
5. Press **OK** to select it, and then press ◄, ►, ▲, or ▼ to adjust the selection.
6. Press **BACK** once to return to the previous screen. To return to your program once adjustments have been completed, press the **EXIT** button on the remote control.

Input Menu

Select the Input Source for your HDTV. Choose from *TV, AV, Comp, HDMI-1, HDMI-2, HDMI SIDE, RGB, and Media.*



Wide Menu

Select how the picture displays on the screen. As you select an option, you will see the screen adjusting to the different sizes. The options vary depending on the selected input and the TV program:

Normal

The original 4:3 aspect ratio (1.33:1 source) is preserved, so black bars are added to the left and right of the display image. Standard TV broadcasts are displayed with a 4:3 Aspect Ratio. Movies in 4:3 Aspect Ratio may be referred to as pan-and-scan or full frame. These movies were originally filmed in 16:9 (widescreen), and then modified to fit a traditional TV screen (4:3).



Wide

Wide mode allows you to view the entire picture. Recommended for HDMI and RGB / Computer viewing so you can see the complete picture without the image overstretching beyond the viewing area. If you experience “noise” along the border switch to Zoom 1. For 720p, 1080i, 1080p only.

Panoramic

When watching a standard broadcast or full frame movie in this mode, the 4:3 Aspect Ratio (1.33:1 source) display image is stretched horizontally on the left and right sides to fill the TV screen. The center of the image is not stretched.



Stretch

When watching a widescreen program (1.78:1 source) with black bars on the sides, the display image will stretch to fill the TV screen. People will appear wider than they really are. If you are watching a widescreen (1.85:1 or 2.35:1 source) program or movie, there will still be black bars at the top and bottom. This mode is available only when watching a widescreen program.



CC (Closed Caption) Menu

Adjust closed caption options.



Analog Closed Caption

The CC feature is available when watching regular analog TV. Select from **Off, CC1, CC2, CC3,** and **CC4**. Closed Caption for regular TV is usually **CC1** or **CC2**.

Digital Closed Caption

The CC feature is available when watching digital TV. Select from **CC1, CC2, CC3, CC4, or CS1, CS2, CS3, CS4, CS5, CS6,** or **Off.**

Digital CC Style

The Digital CC Style feature is available when watching digital TV.

- **Caption Style:** Select either **As Broadcaster** or **Custom**. If **Custom** is selected you can customize the way Closed Caption is displayed. The options available are:
- **Text Size**: Make CC text larger or smaller.
- **Color:** Choose a text color for CC display.
- **Opacity:** Make text more or less transparent.
- **BG Color:** Choose a background color for CC text.
- **BG Opacity:** Make the background for CC text more or less transparent.
- **Window Color:** Choose a text frame color for CC text.
- **Window Opacity:** Make the text frame for CC text more or less transparent.

Sleep Timer Menu

Select the timer to turn off the TV in **30, 60, 90, 120** or **180** minutes.

Picture Menu

Adjust picture options including brightness, contrast, and advanced picture settings.

Picture Mode

Choose from **Standard, Movie, Game, Vivid,** or **Custom**. Each input (i.e. HDMI, COMP, etc) remembers the custom setting you created. Select **Custom** to manually adjust *Backlight, Brightness, Contrast, Color, Tint, Sharpness*, and to access the *More* menu where further adjustments can be made.

Backlight

Adjust the LED brightness to affect the overall brilliance of the picture not the Brightness (black level) or Contrast (white level) of the picture.

Note: Backlight is only available when *Picture Mode* is set to **Custom**.

Brightness

Adjust black levels in the picture. If the brightness is too low you will not be able to see the detail in darker parts of the picture and if the brightness is too high the picture will look washed out.

Note: Brightness is only available when *Picture Mode* is set to **Custom**.

Contrast

Adjust the white levels in the picture. If the contrast is too low the picture will look washed out and if the contrast is too high you will not be able to see any detail in the bright parts of a picture.

Note: Contrast is only available when *Picture Mode* is set to **Custom**.

Color

Adjust the amount of color in the picture.

Note: Color is only available when *Picture Mode* is set to **Custom**.

Tint

Adjust the hue of the picture. The easiest way to set tint is to look at flesh tones and adjust for a realistic appearance. In most cases, the default middle position is correct. If people's faces look too orange try reducing the level of color first.

Note: Tint is only available when *Picture Mode* is set to **Custom**.

Sharpness

Adjust the sharpness of the edges of elements in the picture. It does not produce detail that otherwise does not exist. This adjustment is helpful when viewing Standard Definition sources.

Note: Sharpness is only available when *Picture Mode* is set to **Custom**.

More

Select **More** to adjust advanced options for fine tuning the picture.

Note: The *More* menu is only available when *Picture Mode* is set to **Custom**.

Size & Position

To select the options in the Size & Position sub-menu, press the **MENU** button or the ► button. A new menu will be displayed showing the following Size & Position settings:

- **Horiz. Position**
  Adjust the horizontal position of the picture.
- **Vertical Position**
  Adjust the vertical position of the picture.
- **Horizontal Size**
  Adjust the horizontal size of the picture.
- **Vertical Size**
  Adjust the vertical size of the picture.
- **Auto Phase (for Component input only)**
  The TV will automatically look for the phase of the signal to fine tune the picture.



Note: The *Size & Position* function is only available in HDMI, Component, or RGB modes.

Color Temperature

Color Temperature is the “warmness” or “coolness” of the white areas of the picture. Choose from **Custom**, **Cool**, **Normal**, or **PC**. **Normal** is the setting for television broadcasting. **Custom** allows you to set a preset calibrated for a white point to suit individual preferences. **Cool** produces a blue-hued image. **PC** sets the white point at the established setting for a computer display (9300K). Each preset may also be adjusted for a customized setting.

Advanced Picture

To select the options in the Advanced Picture sub-menu, press **OK**. A new menu will be displayed showing the advanced functions available for fine tuning of the picture.



- **Noise Reduction**

  This feature diminishes picture artifacts caused by the digitizing of image motion content that may be present in the picture. Choose from **Off**, **Low, Medium**, or **High**.

- **Color Enhancement**

  This feature increases the picture reproduction performance of the picture by reducing oversaturation of certain colors and improving flesh tones. Choose from **Off**, **Normal**, **Rich Color**, **Green/Flesh**, and **Green/Blue**.

- **Adaptive Luma**

  Large areas of brightness in the picture will result in a higher Average Picture Level (APL) and the overall picture will look too light. This feature will lower the APL to counteract this effect. Choose from **Off**, **Low**, **Medium**, **Strong**, or **Extend**.

- **Film Mode**

  Choose from **Off** or **Auto**. When set to **Off** it will stay at 60 fps. When set to **Auto**, the TV will detect the cadence (for example at 24 frames/second for film, or normal video at 60 fps).

- **Backlight Control**

  Set this feature to **OFF**, **DCR**, or **OPC**. **DCR** (Dynamic Contrast Ratio) improves the black level performance and increases contrast ratio. **OPC** (Optimum Power Control) Reduces power consumption while maintaining the same picture brightness.

- **Ambient Light Sensor**

  Choose **Off**, **Low, Medium**, or **High**. When set to on, your HDTV will automatically adjust to light changes in the room.

Reset Picture Mode

Return all Picture settings to factory default. A screen will come up to confirm your selection or to cancel it. Press ◄ or ► to make the selection, and then press **OK** to accept it.

Note: Only settings under the Picture will be reset.

Audio Menu

Adjust audio options including balance, equalizer, and advanced audio settings.



Audio Mode

Choose from Flat, Rock, Pop, Classic or Jazz.

Balance

Adjust the sound to the left or the right.

Lip Sync

Lip Sync is designed to adjust the audio of the program being viewed so that it matches the movement of the lips of someone talking on the screen.

TV Speakers

Turn the internal speakers On or Off. You may want to turn the internal speakers off when listening to the audio through your Home Theater System.

Advanced Audio

To select the options in the Advanced Audio sub-menu, press ►. A new menu will be displayed showing the advanced functions available for fine tuning of the audio.

SRS TruSurround HD™

This option sets the SRS True Surround HD™ surround sound process. Choose from On or Off.

Note: When SRS TruSurround HD™ is ON, Equalizer adjustments are not available.

SRS TruVolume

When the programming switches to a commercial or when changing from channel to channel, volume fluctuations occur. When turned ON, SRS TruVolume™ provides the listener with a comfortable and consistent volume level. Turn this option Off when listening to music.

Digital Audio Out

This option allows selection of the type of processing for the S/PDIF (Optical connector) when used with a Receiver/Amplifier/Home Theater system. Select to choose from OFF, Dolby Digital or PCM.

Analog Audio Out

This option sets the volume control properties when using the RCA (white and red) connectors as audio line out to connect a Receiver/Amplifier/Home Theater system. Choose from Fixed or Variable. When set to Variable, volume from the external speakers will change according to the volume setting on the TV. If it is set to Fixed, the volume can only be changed by the settings on the external stereo system.

Equalizer Settings

To select the options in the Equalizer sub-menu, press **OK**. A new menu will be displayed showing the volumes of different frequencies.

Starting from lowest to the highest, they are 120Hz, 500Hz, 1.5kHz, 5kHz and 10kHz.

1. Press ◄ or ► to select the frequency to be adjusted.
2. Use ▲ or ▼ to adjust the selected frequency to your preference. Values above 0 will boost the frequency and values below 0 will attenuate the frequency.

Note: The Equalizer adjustment will only be available when SRS TSHD is set to Off.



Reset Audio Mode

Return all Audio settings to factory default. A screen will come up to confirm your selection or to cancel it. Press ◄ or ► to make the selection, and then press OK to accept it.

Note: Only settings under the Audio menu will be reset.

Settings Menu

Tuner

Note: The tuner option can only be selected when your HDTV is in TV input mode.

Tuner Mode

Select Cable or Antenna depending upon which you have attached to the DTV / TV Input.

Auto Channel Search

Automatically search for TV channels that are available in your area. Be sure to first select the correct tuner mode above. The TV will search for analog and digital channels. When the search is done, press **OK** to begin watching your programs.

Partial Channel Search

If you believe channels are missed from the auto search, you can do a partial channel search to look for channel in a certain channel range again. Select to scan for Analog, Digital, or both Analog/Digital channels, then press the ▼ button to highlight the “From” and “To” selection. Press the ► button to select the range of channel numbers you want to start searching in. Press **OK** to start channel search.



Skip Channel



After the TV has stored all of the available digital channels in memory you will find that some channels are too weak to watch comfortably or they may be channels you do not want to see. Press **OK** to select the channel to be skipped when using the CH+ or CH- button. An X will appear in channels you have selected to skip. You will still be able to select this channel using the number buttons on the remote control.

MTS

This feature allows you to select the different languages the broadcaster is transmitting the audio with the program you are watching. This signal is usually Spanish. Choose from **Mono, Stereo,** or **SAP**.

Name Input

This feature makes it easier for you to recognize the devices you have connected to your HDTV when you press **INPUT**. For example, if you have a Blu-Ray DVD player connected to the HDMI-1 input, you can have the input label read *HDMI-1 BluRay* instead of just *HDMI-1*. You can select from 10 preset labels.

To use one of the 10 preset labels:

1. Select *Input Source*, and then press **OK** to show the list of inputs.
2. Press ▼ to select the input label you want to change, and then press **OK.**
3. Press ▼ to select *Input Labels*, and then press **OK** to show the list of 10 preset labels.
4. Press ▼ to select the new input label name, and then press **OK.**

Parental Controls

If you want to restrict certain channel and program viewing, you can do this by turning on the Parental Control. Selected programs, movies and channels can then be made available only after an authorized password has been entered and accepted by the TV.



To select the options in the Parental sub-menu, press **OK** and then create and/or enter a password. A new menu will be displayed showing the following Parental settings:

Note: The Parental menu does not appear when the input mode is set to HDMI or RGB.

Channel Locks

Block individual channels from being displayed.

USA-TV

Note: When Rating Enable is **OFF**, the USA-TV Rating adjustments are not available.

Press **OK** to block (locked) or allow (unlocked) channels by the following US TV ratings:

- TV-Y – All children
- TV-Y7 – Older children
- TV-G – General audience
- TV-PG – Guidance suggested
- TV-14 – Strongly cautioned
- TV-MA – Mature audience



You can also customize the TV ratings for the following content:

- A – All sub-ratings
- FV – Fantasy violence
- D – Sexual dialog
- L – Adult language
- S – Sexual situations
- V - Violence

USA-Movie



Note: When Rating Enable is **OFF**, USA-Movie Rating adjustments are not available.

Press the **OK** button to block (locked) or allow (unlocked) channels by the following US Movie ratings:

- G – General audience
- PG – Parental guidance suggested
- PG-13 – Recommended for children 13 years of age or older
- R – Mature audience
- NC-17 – No one under 17 years of age
- X – No one under 17 years of age

CAN-English

Note: When Rating Enable is **OFF**, Canadian English Rating adjustments are not available.

Press the **OK** button to block (locked) or allow (unlocked) channels by the following Canadian English ratings:

- C – Children
- C8+ – Children 8 years or older
- G – General Programming, suitable for all audiences
- PG – Parental guidance
- 14+ – Viewers 14 years or older
- 18+ – Adult programming

CAN-French

Note: When Rating Enable is **OFF**, Canadian French Rating adjustments are not available.

Press the **OK** button to block (locked) or allow (unlocked) channels by the following Canadian French ratings:

- G – General audience
- 8 ans+ – General – not recommended for young children
- 13 ans+ – Not suitable for children under 13 years of age
- 16 ans+ – Not suitable for under 16 years of age
- 18 ans+ – Adults only

Alt Rating Region

This is reserved for future use in the event the parental control system is ever updated. Your HDTV will be able to receive and update the new rating system to it.

Block Unrated TV

Block programming that does not have a rating.

Change PIN (Password)

Enter a new, 4-digit password using the number buttons on the remote control. Enter it a second time to confirm you entered it correctly.

Note: Make sure you write down and store the new password in a secure place. The *Reset Locks* feature does NOT reset the password.

RESET LOCKS

Return all Parental Control lock settings to factory default. A screen will come up to confirm your selection or to cancel it. Press ◄ or ► to make the selection, and then press **OK** to accept it.



Menu Language

Select to change the language of the menu. The default is **English**. You can also select **French** or **Spanish**.

Time & Local Settings

Time Zone

Setting the correct Time Zone for your area will ensure that the correct time is shown after pressing the **GUIDE** button on the remote control.

Daylight Saving

Setting the daylight saving time for your area will ensure that the correct time is shown after pressing the **GUIDE** button on the remote control.

CEC

Consumer Electronics Control allows you to control other devices using your HDTV remote control when those devices are connected via HDMI. For example, if a CEC-supported Blu-ray DVD player is connected to your HDTV through HDMI-2 and that player is powered on, your HDTV will automatically change to the HDMI-2 input. Similarly, if your HDTV is powered on first and your change the input to HDMI-2, your Blu-ray player will automatically power on.



Also, you can control your CEC-supported device using the transport keys on your HDTV remote control (e.g. Play, Stop, Prev, etc.). When you press one of the buttons on your HDTV, the action will occur on your device.

Contact your devices' user manual or manufacturer to check whether your device supports CEC.

CEC Function

Turn CEC On or Off. When set to Off, your HDTV will not send or receive any CEC commands.

Device Discovery

Register device with TV. Before CEC will work, perform a Device Discovery to see if there are any CEC supported devices connected to your HDTV.

Media Menu

When viewing pictures you can adjust various settings, including slideshow, picture duration, etc.

1. Insert a USB device containing pictures and select the folder or files that you want to play.
2. Press **MENU**. The Picture menu will be displayed.
3. Press ▲ or ▼ on the remote control to highlight a Picture menu option, and then press ◄ or ► to adjust the setting.
4. Press **MENU** once to close the menu.

Slideshow Mode

Choose from **Shuffle, Single,** and **Sequence** to set the slideshow mode. Press **OK** to begin the slideshow. Press **EXIT** to stop the slideshow.

- **Single** will display one picture selected from the thumbnails for the interval set in the *Duration* option and return to the thumbnails. If the *Repeat* option is set to **On**, the selected picture will be displayed until you press **EXIT**.
- **Sequence** will show your pictures in the order they are listed on your USB device until you stop the slideshow.
- **Shuffle** will show your pictures in random order until you stop the slideshow.

Repeat

Choose from **On** or **Off** to repeat the slideshow.

Sort By

You can choose to sort the pictures on the USB device by **Photo Date**, **File Date**, or alphabetically (**File A-Z**).

Duration

Set the amount of time the picture will remain on the screen during the slideshow. Choose a time between 5 seconds and 32 seconds.

Slideshow Effect

Choose from **Random, Dissolve, Wipe Right, Wipe Left, Wipe Up, Wipe Down, Box In,** or **Box Out** to set the transition type when changing from one picture to another during a slideshow.

Thumbnail Size

Set the size of the preview pictures (thumbnails) in the menu. Choose from **Small, Medium,** or **Large.**

Info

When set to **On**, information about the picture briefly appears on your HDTV.

Help Menu

System Info

Display the technical information including model name, version and revision of firmware, source type, and resolution.

Reset TV Settings

Return all Picture and Audio settings to factory default. A screen will come up to confirm your selection or to cancel it. Press Left or Right Navigation buttons to make the selection, and then press **OK** to accept it.

Note: This does **NOT** reset the Parental Control Password.

Clear Memory (Factory Default)

Use this function to reset the TV to the default factory settings. The screen will display a message to confirm that you want to reset the values to factory settings. Press ◄ or ► to make the selection, and then press **OK** to accept it.

Note: This does **NOT** reset the Parental Control Password.

Start Setup Wizard

Use this function to return to the Initial Setup menu. Use this function if you want to have a guided setup when you move your TV. Refer to Chapter 3 for more information.

Note: Previously scanned channels will be removed.

Chapter 9 Programming the VIZIO Universal Remote Control

Using a Cable or Satellite Box Remote

Your VIZIO remote uses codes 000, 047, 050, 067, 329, 331 and 339 to work your HDTV. To use a Cable or Satellite remote to work the HDTV, refer to your Cable or Satellite remote user guide for more information on how to program the remote.

If your Cable or Satellite remote uses a 5-digit code (like most Direct TV units), first try 11758 and then, if that does not work, 10178. If your Cable or Satellite remote uses a 4-digit code, try 1758 and then 0178 as an alternative. If your Cable or Satellite remote uses a 3-digit code (Echostar or Dish Network for example), use code 627.

Note: Some buttons may not function as expected on your Cable or Satellite remote. Typically power, volume and mute will work.

Programming other devices

Your remote control is programmable and supports up to three different devices. Listed below are the steps for programming your DVD player, Home Theater System, and a Cable or Satellite box. After you find your codes, write them in the table provided.

Programming your Blu-Ray or DVD Player

1. Turn on the DVD player.
2. Press and release the **DVD** button on your VIZIO universal remote control.
3. Press and hold the **SET** button until the LED flashes twice.
4. Find the programming code for your DVD player in the code list below and enter it using the number buttons. If the code is accepted, the LED flashes twice after the last digit is entered. If the LED does not flash twice, repeat Steps 2 through 4 with the next code listed.
5. Point the remote control at the DVD player and press **POWER**. The DVD player will turn off. If the DVD player does not turn off, repeat Steps 2 through 4 with the next code listed for the component and manufacturer.

Notes:

- If the codes do not work or your brand is not listed, see *Searching for Device Codes* on page 43.
- Sometimes a code listed will only include limited functions. Try other codes that may include more functionality.

Programming your Home Theater System

1. Turn on the Home Theater System.
2. Press and release the **AUDIO** button on your VIZIO universal remote control.
3. Press and hold the **SET** button until the LED flashes twice.
4. Find the programming code for your Home Theater System and enter it using the number buttons. If the code is accepted, the LED flashes twice after the last digit is entered. If the LED does not flash twice, repeat Steps 2 through 4 with the next code listed.
5. Point the remote control at the Home Theater System and press **POWER**. The Home Theater System will turn off. If the Home Theater System does not turn off, repeat Steps 2 through 4 with the next code listed for the component and manufacturer.

Notes:

- If the codes do not work or your brand is not listed, see *Searching for Device Codes* on page 43.
- Sometimes a code listed will only include limited functions. Try other codes that may include more functionality.

Programming your Cable or Satellite Set-Top Box

1. Turn on the Cable or Satellite Set-Top Box.
2. Press and release the **CABLE** button on your VIZIO universal remote control.
3. Press and hold the **SET** button until the LED flashes twice.
4. Find the programming code for your Cable or Satellite Set-Top Box and enter it using the number buttons. If the code is accepted, the LED flashes twice after the last digit is entered. If the LED does not flash twice, repeat Steps 2 through 4 with the next code listed.
5. Point the remote control at the Cable or Satellite Set-Top Box and press **POWER**. The Cable or Satellite Set-Top Box will turn off. If the Cable or Satellite Set-Top Box does not turn off, repeat Steps 2 through 4 with the next code listed for the component and manufacturer.

My Codes	
DVD Player	
Home Theater	
Cable Box	
Satellite Box	
VCR	
Other	
Other	
Other	

Notes:

- If the codes do not work or your brand is not listed, see *Searching for Device Codes* on page 43.
- Sometimes a code listed will only include limited functions. Try other codes that may include more functionality.

Searching for Device Codes

If you cannot find the manufacturer in the list or the program code does not work, you can use the remote control to search for the correct device code.

1. Turn on the device.
2. Press the matching device button on your VIZIO universal remote control.
3. Press and hold **SET** until the LED flashes twice.
4. Press **9 9 1**. The LED flashes twice.
5. Point the remote control at the device and then press and hold **POWER** until the device turns off.

Reset Remote Control to Factory Settings

1. Press and hold **SET** until the LED flashes twice.
2. Press **9 1 9 1 9**. The LED flashes twice.

Remote Control Codes

Television Codes

(Including TV/DVD, TV/VCR, and TV/DVD/VCR)

3M 10195, 888, 10462

A.R. Systems 10352

Abex 10065, 10256

ACE 10449

Acer 10164

Addison 10048, 10231

Admiral: 10045, 10078, 10232, 10236

Advent 10221, 10291

Adventura 10066, 10261

Aiko 10053, 10231

Aim 10353

Aiwa 10178, 10207

Akai 10027, 10046, 10127, 10153, 10196, 10229, 10238, 10240, 10254, 10267, 10304, 10353

Akiba 10353

Akito 10348, 10353

Akura 10277, 10353

Alaron 10246, 10273, 10275

Alba 10353

Albatron 10219, 10222, 10286

Alfide 10240

Alleron 10055

Allstar 10353

A-Mark 10248

America Action 10234

Ampro 10220, 10289

Amstrad 10279, 10353

Amtron 10054

Anam 10234

Anam National 10054, 10264

Anhua 10455

Anitech 10353

AOC 10047, 10048, 10049, 10112, 10229, 10248, 10252, 10254, 10263, 10274, 10316

Aolinpiya 10462

Aolinpu 10465

Apex 10075, 10095, 10233

Apex Digital 10288

Archer 10248

Archos 10156

Ardem 10353

Aristona 10353

Asberg 10353

Astar 10163

Atlantic 10353

Audinac 10234, 10278

Audiosonic 10352, 10353

Audiovox 10054, 10099, 10231, 10234, 10248, 10280, 10287, 10326

Aventura 10042

Awa 10048, 10351

Axion 10154, 10326

Baihehua 10461

Baihua 10460, 10462

Baile 10458, 10460

Bang & Olufsen 10244

BaoHuaShi 10462

Baosheng 10457, 10460

Barco 10282

Basic Line 10352, 10353

Baur 10249, 10281, 10353

Baysonic 10234

Beijing 10358, 10360, 10362, 10364, 10365, 10366, 10367, 10368, 10369, 10370, 10371, 10372, 10373, 10374, 10376, 10377, 10378, 10379, 10380, 10383, 10384, 10385, 10392, 10394, 10428, 10431, 10448, 10457, 10458, 10460, 10461, 10462

Belcor 10047, 10252

Bell & Howell 10045

Benq 10116, 10159, 10226, 10300

Beon 10353

Bestar 10352, 10353

Bestar-Daewoo 10352

Blaupunkt 10281

Blue Sky 10282, 10353

Boots 10348

Boxlight 10290

BPL 10275, 10353

Bradford 10054, 10234

Brillian 10160

Brinkmann 10353

Brockwood 10047, 10252

Broksonic 10078, 10234, 10236, 10248

Bush 10348, 10352, 10353

byd:sign 10214

Caihong 10360, 10362, 10368, 10457, 10460

Cailing 10464

Caixing 10366, 10367, 10378, 10380, 10390, 10461

Candle 10047, 10049, 10050, 10066, 10229, 10254, 10261, 10265

Carena 10353

Carnivale 10229, 10254

Carver 10034, 10044, 10271

Cascade 10353

Casio 10353

Cathay 10353

Caton 10355

CCE 10246, 10258, 10353

Celebrity 10046

Celera 10075

Centurion 10051, 10353

Changcheng 10357, 10360, 10362, 10363, 10364, 10366, 10367, 10368, 10369, 10370, 10371, 10372, 10373, 10374, 10376, 10378, 10379, 10380, 10384, 10385, 10392, 10448, 10455, 10457, 10458, 10460, 10461, 10462

Changfei 10360, 10362, 10368, 10379, 10457, 10460, 10467

Changfeng 10360, 10367, 10376, 10381, 10382, 10384, 10385, 10392, 10457, 10462

Changhai 10360, 10362, 10368, 10457, 10460, 10467

Changhong 10075, 10356, 10358, 10359, 10360, 10361, 10362, 10369, 10371, 10376, 10383, 10386, 10387, 10388, 10389, 10393, 10394, 10412, 10427, 10433, 10436, 10448, 10457, 10460

Chaparral 10442

Chengdu 10360, 10368, 10457

Chimei 10217

Ching Tai 10231

Chun Yun 10222, 10231, 10234, 10329, 10342

Chunfeng 10362, 10368, 10376, 10384, 10385, 10392, 10405, 10460, 10462

Chung Hsin 10048, 10234, 10332

Chunlan 10397, 10468

Chunsun 10360, 10362, 10368, 10457, 10460

Cinego 10327

Cineral 10231, 10280

Citizen 10047, 10049, 10050, 10053, 10054, 10062, 10064, 10229, 10231, 10238, 10254, 10259, 10261, 10265, 10325, 10347

Clairtone 10274

Clarion 10234

Clarivox 10353

Clatronic 10353

Coby 10108

Colortyme 10047, 10049

Colt 10344

Commercial Solutions 10230

Concerto 10047, 10049, 10265

Condor 10353

Conrowa 10422, 10460, 10462

Contec 10234, 10268, 10269, 10274, 10353

Contec/Cony 10052, 10054

Cosmel 10353

Craig 10054, 10234

Crosley 10034, 10044, 10076

Crown 10054, 10058, 10234, 10240, 10259, 10353

Crown Mustang 10240

CTX 10115

Curtis Mathes 10016, 10027, 10034, 10044, 10047, 10049, 10062, 10064, 10229, 10230, 10232, 10238, 10239, 10254, 10259, 10265, 10280

CXC 10054, 10234

CyberHome 10294

Cytron 10152, 10310

Daewoo 10047, 10048, 10049, 10053, 10064, 10076, 10231, 10240, 10252, 10259, 10280, 10325, 10347, 10352, 10353

Dansai 10353

Dawa 10353

Daytron 10047, 10049, 10064, 10252, 10352, 10353

Dayu 10458

De Graaf 10275

Decca 10348, 10353

Dell 10019, 10124

Denon 10239

Denstar 10284

Denver 10353

Desmet 10353

Diamant 10353

Diamond Vision 10216, 10328

Digatron 10353

Dimensia 10016

Disney 10093

Dixi 10353

DongBao 10448

DongDa 10362, 10368, 10448, 10460

Donghai 10362, 10368, 10460

DongHua 10448

Donglin 10391

Dual 10353

Dumont 10020, 10047, 10228, 10252, 10266

Durabrand 10042, 10078, 10227, 10234, 10236, 10248, 10272

Dux 10353

D-Vision 10353

Dwin 10232, 10293

Dynatech 10262

Dynatron 10353

Dynex 10143, 10189

Ectec 10278

Eiki 10169, 10170

Electroband 10046, 10274

Electrograph 10206, 10321

Electrohome 10046, 10047, 10049, 10078

Elektra 10228

Element 10136

ELG 10353

Elin 10353

Emerson 10042, 10047, 10049, 10052, 10054, 10055, 10064, 10076, 10078, 10135, 10234, 10236, 10252, 10259, 10269, 10272, 10273, 10274, 10325, 10347, 10353

Emprex 10215

Envision 10047, 10049, 10112, 10229, 10254, 10316

Epson 10113, 10302

Erres 10250, 10353

ESA 10042, 10127

ESC 10353

Ether 10330

Euroman 10353

Europa 10353

Exquisit 10353

Feilang 10362, 10368, 10460

Feilu 10360, 10362, 10368, 10457, 10460

Feiyan 10376, 10384, 10385, 10392, 10462

Feiyue 10360, 10362, 10366, 10367, 10368, 10378, 10380, 10457, 10460, 10461

Fenmenti 10353

Fenner 10352

Ferguson 10048

Fidelity 10353

Filmnet 10440

Finlandia 10275

Finlux 10266

Firstline 10352, 10353

Firstar 10340

Fisher 10270, 10275

FlexVision 10287

Flint 10353

Fraba 10353

Friac 10353

Frontech 10277

Fujitsu 10050, 10055, 10208, 10273

Funai 10042, 10054, 10055, 10234, 10273, 10324

Furi 10336

Futuretech 10054, 10234, 10277

Galaxis 10353

Ganxin 10457, 10461

Gateway 10119, 10206, 10241, 10322

GBC 10352

GE 10016, 10047, 10049, 10056, 10057, 10070, 10088, 10230, 10253, 10264, 10272, 10280, 10345

GEC 10353

Geloso 10352

Genexxa 10353

GFM 10040, 10140

Gibralter 10020, 10047, 10228, 10229, 10252, 10254

GoldStar 10047, 10048, 10049, 10052, 10064, 10065, 10229, 10252, 10254, 10256, 10272, 10346, 10353

Goodmans 10352, 10353

Gradiente 10036, 10118, 10265, 10271

Granada 10048, 10275, 10353

Grandin 10352, 10353

Great Wall 10349

Grundig 10240, 10258, 10266, 10281, 10353

Grunpy 10054, 10055, 10234, 10273

Haier 10139, 10148, 10174, 10209, 10227, 10247, 10354, 10380, 10395, 10396, 10399, 10403, 10404, 10414, 10416, 10417, 10418, 10419, 10421, 10423, 10424, 10466

HaiHong 10362, 10368, 10369, 10370, 10371, 10372, 10373, 10391, 10395, 10448, 10460

Haile 10375

Haiyan 10360, 10366, 10367, 10376, 10378, 10380, 10384, 10385, 10392, 10457, 10461, 10462

Hallmark 10047, 10049, 10272

Hankook 10234, 10330, 10339

Hannspree 10315

Hanseatic 10353

Hantarex 10313, 10353

Hantor 10353

Harley Davidson 10260, 10273, 10324

Harman/Kardon 10034, 10044

Harvard 10054, 10234

Harwood 10353

Hauppauge 10353

Havermy 10232

HCM 10279, 10353

Helios 10145

Hello Kitty 10210, 10280

Hewlett Packard 10101, 10301

Highline 10353

Himitsu 10234, 10284

Hinari 10353

Hisense 10121, 10288, 10338, 10350, 10356, 10358, 10361, 10368, 10381, 10382, 10386, 10395, 10396, 10397, 10400, 10401, 10407, 10408, 10416, 10417, 10418, 10419, 10426, 10428, 10431, 10459

Hitachi 10047, 10048, 10049, 10052, 10131, 10184, 10239, 10256, 10265, 10324, 10353

Hitachi Fujian 10048, 10457, 10459, 10461, 10462

Hornyphone 10353

Hongmei 10359, 10360, 10362, 10366, 10367, 10368, 10376, 10378, 10380, 10385, 10386, 10387, 10392, 10457, 10460, 10461, 10462

Hongyan 10457, 10462

Hotel TV 10447

HP 10301

Huafa 10460

Huanghaimei 10362, 10368, 10460

Huanghe 10360, 10362, 10366, 10367, 10368, 10378, 10380, 10383, 10395, 10406, 10457, 10460, 10461

Huanglong 10362, 10368, 10460

Huangshan 10360, 10362, 10366, 10367, 10368, 10375, 10376, 10378, 10380, 10384, 10385, 10392, 10457, 10460, 10461, 10462

Huanyu 10352, 10359, 10360, 10366, 10367, 10376, 10378, 10380, 10384, 10385, 10386, 10387, 10392, 10457, 10459, 10461, 10462

Huaqiang 10376, 10384, 10385, 10392, 10462

Huari 10462

Humax 10197

Huodateji 10455

Hypson 10277, 10353

Hyundai 10171, 10224

Iberia 10353

ICE 10277

Ilo 10149, 10151, 10307, 10320

IMA 10054

Imperial 10353

Imperial Crown 10458, 10462

Indiana 10353

Infinity 10034, 10044, 10058

InFocus 10125, 10290

Initial 10151, 10320

Innova 10258

Insignia 10141, 10142, 10143, 10181, 10310

Inteq 10228

Interbuy 10353

Interfunk 10353

Internal 10353

Intervision 10277, 10353

IR 10351, 10352, 10353

Irradio 10353

IRT 10280, 10284

Isukai 10353

ITS 10353

ITV 10352, 10353

Janeil 10066, 10261

JBL 10034, 10044, 10058

JC Penney 10016, 10047, 10048, 10049, 10050, 10056, 10057, 10062, 10064, 10065

JCB 10046

Jean 10231, 10331, 10338, 10340

Jensen 10047, 10049, 10291

Jiahua 10357, 10363, 10375, 10376, 10411, 10455

JiaLiCai 10414, 10448, 10460, 10462

Jinfeng 10357, 10360, 10365, 10455, 10457

Jinhai 10359, 10386, 10387

Jinlipu 10386

Jinque 10457, 10460, 10462

Jinta 10460, 10461, 10462

Jinxing 10333, 10336, 10338, 10358, 10360, 10367, 10368, 10375, 10376, 10377, 10383, 10386, 10389, 10390, 10392, 10394, 10397, 10408, 10426, 10457, 10462

Juhua 10457, 10461, 10462

JVC 10036, 10037, 10038, 10052, 10057, 10059, 10078, 10257

Kaige 10457, 10460, 10461, 10462

Kaisui 10353

Kamp 10246

Kangchong 10359, 10386, 10387

Kanghua 10395

Kangli 10422, 10448, 10457, 10458, 10460, 10461, 10462

Kangyi 10390, 10460, 10462

Kawasho 10046, 10047, 10049, 10246, 10269

Kaypani 10263

KDS 10295

KEC 10234

Kendo 10353

Kenwood 10047, 10049, 10229, 10252, 10254

Kioto 10034, 10282

Kiton 10353

KLH 10075

Kloss 10261

Kloss Novabeam 10054, 10066

Kneissel 10352, 10353

Kolin 10048, 10234, 10337

Kongque 10457, 10460, 10461, 10462

Konka 10211, 10237, 10284, 10353, 10355, 10360, 10363, 10372, 10375, 10388, 10389, 10391, 10392, 10397, 10402, 10430

Korpel 10353

Kost 10306

Kreisen 10298

KTV 10054, 10064, 10229, 10234, 10246, 10254, 10259, 10274

Kuaile 10460, 10462

Kunlun 10357, 10360, 10365, 10368, 10376, 10377, 10378, 10379, 10455, 10457, 10458, 10462

Lecson 10353

Lenco 10352, 10353

Leyco 10277, 10353

LG 10019, 10048, 10100, 10129, 10167, 10175, 10185, 10198, 10199, 10200, 10219, 10225, 10245, 10254, 10265, 10272, 10286, 10323, 10353

Liesenk & Tter 10353

Lifetec 10352, 10353

Lihua 10457

Lloyd's 10324

Local India TV 10275

Loewe 10058

Loewe Opta 10353

Logik 10045, 10351

Longjiang 10360, 10376, 10384, 10385, 10392, 10457, 10462

Lumatron 10353

Lux May 10353

Luxman 10047, 10049, 10265

LXI 10016, 10034, 10044, 10049, 10058, 10230, 10233, 10272

M & S 10034

Melectronic 10352, 10353

Madison 10353

MAG 10295

Magnasonic 10325, 10347

Magnavox 10034, 10044, 10047, 10049, 10050, 10058, 10073, 10086, 10089, 10134, 10229, 10254, 10257, 10273, 10316, 10324, 10351

Magnin 10345

Magnum 10353

Majestic 10045

Manesth 10277, 10353

Manhattan 10353

Marantz 10034, 10044, 10047, 10049, 10058, 10114, 10212, 10229, 10254, 10258, 10353

Mark 10352, 10353

Matsui 10275, 10348, 10351, 10353

Matsushita 10235, 10285

Maxent 10144, 10201, 10206, 10292

Mediator 10250, 10353

Medion 10353

Megapower 10219, 10286

Megatron 10049, 10239, 10248, 10272

MEI 10274

Meile 10457, 10461, 10462

MeiShi 10390

Memorex 10042, 10045, 10048, 10049, 10078, 10236, 10272, 10273, 10343, 10346

Mengmei 10461

Mercury 10353

Metz 10281, 10353

MGA 10047, 10048, 10049, 10229, 10252, 10254, 10272, 10345

Micromaxx 10353

Midland 10020, 10057, 10064, 10065, 10228, 10230, 10256, 10259

Minato 10353

Minerva 10048, 10266, 10281

Minoka 10279, 10353

Mintek 10151, 10320

Minutz 10056, 10253

Mitsubishi 10047, 10048, 10049, 10092, 10182, 10183, 10232, 10252, 10267, 10272, 10281, 10353

MoDeng 10390

Monivision 10219, 10222, 10286

Montgomery Ward 10045

Morgans 10353

Motorola 10232, 10264, 10295

Moxell 10295

MTC 10047, 10048, 10049, 10062, 10229, 10238, 10246, 10252, 10254, 10262, 10265, 10274

MTEC 10348

MuDan 10380, 10411, 10438, 10455, 10457, 10460, 10462

Multitec 10353

Multitech 10054, 10234, 10246, 10262, 10353

Multivision 10060

NAD 10049, 10233, 10258, 10265, 10272

Naiko 10353

Nakamichi 10318

Nanbao 10460, 10462

Nansheng 10360, 10376, 10384, 10385, 10392, 10457, 10462

NEC 10047, 10048, 10049, 10162, 10212, 10218, 10229, 10252, 10254, 10257, 10265, 10271, 10351, 10352

Neckermann 10353

NEI 10353

Neovia 10313

Netsat 10258, 10353

Net-TV 10158, 10206, 10292

Neufunk 10353

New Tech 10353

Newave 10231, 10335, 10339

Nikkai 10277, 10353

Nikko 10049, 10053, 10229, 10231, 10254, 10272

Nisato 10278

Nokia 10352

Norcent 10112, 10288, 10301, 10316

Nordmende 10353

Normerel 10353

Norwood Micro 10307

Noshi 10251

Novatronic 10352, 10353

NTC 10053, 10231

Okano 10353

Olevia 10096, 10105, 10111, 10242, 10243, 10303, 10305, 10311

Olympus 10314

Onwa 10054, 10234

Opera 10353

Oppo 10155

Optimus 10235, 10285, 10343

Optoma 10126, 10194

Optonica 10061, 10232

Orbit 10353

Orion 10078, 10193, 10236, 10273, 10351, 10353

Orline 10353

Osaki 10277, 10279, 10348, 10352, 10353

Osio 10353

Osume 10353

Otto Versand 10249, 10281, 10353

Palladium 10353

Palsonic 10353

Panama 10277, 10353

Panasonic 10010, 10011, 10012, 10013, 10014, 10015, 10048, 10057, 10058, 10080, 10085, 10102, 10173, 10176, 10235, 10264, 10285, 10343

Panasonic/National 10353

Panavision 10353

Panda 10357, 10359, 10360, 10362, 10365, 10366, 10367, 10368, 10369, 10371, 10376, 10378, 10380, 10383, 10384, 10385, 10386, 10387, 10390, 10392, 10394, 10405, 10406, 10415, 10422, 10455, 10457, 10460, 10461, 10462

Penney 10229, 10230, 10233, 10238, 10248, 10251, 10252, 10253, 10254, 10256, 10259, 10272, 10345, 10346

Perdio 10353

Perfekt 10353

Philco 10034, 10044, 10047, 10048, 10049, 10050, 10052, 10058, 10078, 10229, 10252, 10254, 10353

Philips 10029, 10030, 10031, 10032, 10033, 10034, 10035, 10044, 10047, 10048, 10050, 10052, 10058, 10072, 10074, 10104, 10134, 10177, 10187, 10250, 10258, 10282, 10352, 10353

Philips Magnavox 10031, 10034, 10072, 10073

Phoenix 10353

Phonola 10250, 10353

Pilot 10047, 10064, 10229, 10252, 10254, 10259, 10450, 10451, 10452, 10453, 10454

Pioneer 10047, 10049, 10212, 10353

Pionier 10353

Plantron 10353

Plasmsync 10165

Playsonic 10353

Polaroid 10075, 10100, 10109, 10136, 10145, 10190, 10295, 10306, 10310

Polestar 10441

Portland 10047, 10048, 10049, 10053, 10064, 10231, 10252, 10259, 10352

Powerpoint 10353

Praxis 10443

Price Club 10062

Prima 10117, 10148, 10213, 10221, 10291

Princeton 10219, 10286

Prism 10057

Profitronic 10353

Proline 10353

Proscan 10016, 10230

Prosonic 10352, 10353

Protech 10277, 10353

Proton 10047, 10049, 10052, 10248, 10255, 10263, 10272

Protron 10106, 10309

Proview 10120, 10136, 10295

Provision 10353

Pulsar 10020, 10047, 10228, 10252

Pye 10250, 10352, 10353

Qingdao 10455, 10457, 10462

Quasar 10057, 10235, 10264, 10285, 10343

Quelle 10249, 10266, 10281, 10351, 10353, 10437

Radio Shack/Realistic 10016, 10047, 10049, 10052, 10054, 10061, 10064, 10065

Radiola 10250, 10353

Radiomarelli 10353

RadioShack 10016, 10229, 10230, 10234, 10252, 10254, 10256, 10259, 10265, 10272, 10324, 10353

Radiotone 10353

RBM 10266

RCA 10016, 10017, 10018, 10047, 10048, 10049, 10068, 10077, 10081, 10188, 10230, 10238, 10251, 10252, 10345

Realistic 10016, 10229, 10234, 10252, 10254, 10256, 10259, 10265, 10272

Recor 10353

Rectiligne 10353

Reflex 10353

Revox 10353

Rex 10277

RFT 10353

Rhapsody 10246, 10274

R-Line 10353

Roadstar 10277, 10353

Rowa 10429

Runco 10020, 10212, 10218, 10228, 10229, 10254

Ruyi 10457, 10459, 10461

Saige 10457, 10460

Saisho 10277, 10351

Saivod 10353

Sampo 10047, 10049, 10064, 10065, 10161, 10206, 10229, 10254, 10256, 10259, 10263, 10292

Samsung 10026, 10027, 10028, 10047, 10048, 10049, 10052, 10062, 10064, 10065, 10127, 10128, 10132, 10137, 10138, 10168, 10229, 10238, 10252, 10254, 10256, 10258, 10265, 10272, 10277, 10353

Samsux 10259

Sanjian 10462

Sansei 10280

Sansui 10078, 10107, 10236, 10324, 10353

Sanyo 10047, 10048, 10097, 10192, 10202, 10270, 10275, 10345, 10351

Sanyuan 10360, 10362, 10366, 10367, 10368, 10378, 10380, 10457, 10460, 10461

SBR 10250, 10353

Sceptre 10123

Schneider 10353

Scimitsu 10252

Scotch 10049, 10272

Scott 10047, 10049, 10052, 10054, 10055, 10150, 10234, 10252, 10272, 10273

Sears 10016, 10034, 10042, 10044, 10047, 10049, 10055, 10059, 10067, 10160, 10230, 10233, 10265, 10270, 10272, 10273, 10324, 10346

Seg 10277, 10353

SEI 10249, 10353

SEI-Sinudyne 10353

Semivox 10234

Shancha 10457, 10462

Shangguangdian 10445

Shanghai 10359, 10360, 10362, 10363, 10366, 10367, 10368, 10376, 10378, 10380, 10384, 10385, 10386, 10387, 10392, 10457, 10460, 10461, 10462, 10467

Shanshui 10358

Shaofeng 10356, 10360, 10366, 10457, 10459, 10461

Sharp 10022, 10023, 10024, 10025, 10047, 10049, 10052, 10061, 10064, 10103, 10232, 10259, 10268

Shen Ying 10231

Shencai 10362, 10368, 10376, 10384, 10385, 10392, 10460, 10462

Sheng Chia 10232, 10335

ShengCai 10386, 10448

Shengli 10456

Shenyang 10360, 10362, 10368, 10376, 10381, 10382, 10457, 10460, 10462

Sherwood 10460

Shintoshi 10353

Shivaki 10353

Shogun 10047, 10252

Shuyuan 10422

Siemens 10281, 10353

Signature 10045

Signet 10306

Silva 10353

Silva Schneider 10353

SIM2 Multimedia 10308

Simpson 10050

Singer 10353

Sinudyne 10249, 10353

Sky 10258, 10353

Skygiant 10234

Skyworth 10360, 10368, 10376, 10381, 10382, 10389, 10390, 10392, 10397, 10409, 10413, 10415, 10420, 10432, 10457, 10462

Solavox 10353

Songbai 10460

SongRi 10448

Soniko 10353

Sonitron 10275

Sonneclair 10353

Sonoko 10353

Sonolor 10275

Sontec 10353

Sony 10000, 10001, 10002, 10003, 10004, 10005, 10046, 10071, 10084, 10130, 10172, 10249, 10324, 10351, 10353

Sound & Vision 10352

Soundesign 10047, 10049, 10050, 10054, 10055, 10234, 10272, 10273

Soundwave 10353

Sova 10309

Sowa 10334, 10338

SOYO 10180, 10319

Spectricon 10248

Spectroniq 10295

Squareview 10042, 10067

Srypton 10353

SSS 10047, 10054, 10234, 10252

Standard 10352, 10353

Starlite 10054, 10234, 10353

Strato 10353

Studio Experience 10222

Sunstar 10353

Sunwood 10353

SuperScan 10041, 10232, 10297

SuperTech 10353

Supre-Macy 10066, 10261

Supreme 10046

SVA 10145, 10247, 10283, 10288

Sylvania 10034, 10035, 10039, 10040, 10041, 10042, 10043, 10044, 10047, 10049, 10050, 10058, 10133, 10229, 10254

Symphonic 10041, 10042, 10054, 10067, 10234, 10324

Synco 10231, 10280, 10329, 10334, 10335, 10339

Syntax 10105, 10243, 10303, 10305, 10311

Syntax-Brillian 10105, 10160

Sysline 10353

Tacico 10231, 10339

Tactus 10348

Tai Wah 10444

Taishan 10360, 10362, 10368, 10370, 10371, 10372, 10373, 10374, 10379, 10457, 10460

Tandy 10232

Tantec 10348

Tashiko 10353

Tatung 10147, 10179, 10241, 10248, 10262, 10264, 10307, 10322, 10331, 10334, 10338, 10348, 10351

TCL 10383, 10384, 10389, 10390, 10398, 10410, 10420, 10425, 10429, 10463

Teac 10277, 10279, 10353

Tec 10353

Tech Line 10353

Technics 10057, 10235

Technol Ace 10273

Technovision 10446

Techview 10223, 10296

Techwood 10047, 10049, 10057, 10248, 10265

Teco 10331, 10335, 10339

Teknika 10034, 10044, 10045, 10047, 10048, 10049, 10050, 10052, 10053, 10054, 10055, 10062, 10064, 10231, 10234, 10238, 10252, 10259, 10265, 10273

Telecaption 10063

Telecor 10353

Telefunken 10027, 10265, 10353

Telefusion 10353

Telegazi 10353

Telesonic 10353

Telestar 10353

Teletech 10353

Teleview 10353

Tennessee 10353

Tensai 10352, 10353

Tera 10255
Tevion 10353
Texet 10352
Thomas 10324
Thomson 10016, 10353
Thorn 10348, 10353
Thorn-Ferguson 10438
Tiane 10457
TMK 10047, 10049, 10265, 10272
TNCi 10228
TOBO 10460, 10462
Tokai 10352, 10353
Tongguang 10376, 10384, 10385, 10392, 10462
Tophouse 10234
Toshiba 10006, 10007, 10008, 10009, 10062, 10063, 10079, 10082, 10083, 10087, 10090, 10091, 10212, 10233, 10238, 10245, 10257, 10266, 10285
Tosonic 10274
Totevision 10064, 10259
Trans Continens 10353
Transonic 10353
Trical 10268
Trutech 10146
Tuntex 10231, 10330
TVS 10078, 10236
Uher 10352, 10353
Ultra 10278
Ultravox 10353
Unic Line 10353
United 10353
Universal 10056, 10353
Universum 10277, 10281, 10351, 10353
Univox 10353
US Logic 10307
Vector Research 10229, 10254
Vegavox 10439
Vestel 10353
Vexa 10353
Vibrant 10348
Victor 10036, 10059
Video Concepts 10267
Videocon 10436
Videosystem 10353
Vidikron 10034, 10044, 10212, 10276
Vidtech 10047, 10048, 10049, 10252, 10257, 10272
Viewsonic 10094, 10110, 10191, 10203, 10204, 10205, 10206, 10297, 10299, 10314
Viking 10066, 10261
Viore 10149, 10304
Visart 10312
Visco 10157
Vision 10353
Vito 10434
Vizio 10047, 10094, 10122, 10166, 10241, 10297, 10299, 10322, 10323, 11000
Vortec 10353
Waltham 10353
Wards 10016, 10034, 10044, 10045, 10047, 10048, 10049, 10055, 10056, 10058, 10061, 10229, 10252, 10253, 10254, 10265, 10272, 10273
Warumaia 10458
Watson 10353
Wega 10353
Wega Color 10435
Weipai 10460
Westinghouse 10094, 10098, 10186, 10299
Wharfedale 10353
White Westinghouse 10076, 10078, 10236, 10353
WinBook 10317
Wyse 10316
Xiahua 10360, 10362, 10367, 10368, 10370, 10376, 10380, 10384, 10385, 10390, 10392, 10425, 10457, 10460, 10462
Xiangyang 10376, 10384, 10385, 10392, 10462
Xiangyu 10362, 10368, 10375, 10460
Xihu 10360, 10366, 10367, 10376, 10378, 10380, 10384, 10392, 10422, 10457, 10461, 10462
Xinaghai 10460, 10462
Xingfu 10362, 10368, 10460
Xinghai 10362, 10368, 10376, 10384, 10385, 10392
Xinsida 10467
Xuelian 10359, 10366, 10367, 10378, 10380, 10386, 10387, 10461
Yamaha 10047, 10048, 10049, 10229, 10252, 10254
Yamishi 10353
Yapshe 10341
YingGe 10448, 10460, 10461
Yoko 10277
Yonggu 10460, 10461
Youlanasi 10457, 10461
Yousida 10460
Yuhang 10362, 10368, 10460
Zenith 10019, 10020, 10021, 10045, 10047, 10069, 10078, 10198, 10228, 10231, 10236, 10245, 10272, 10324
Zhuhai 10362, 10368, 10379, 10460
Zonda 10248

Cable Box Codes

(Including Cable / PVR Boxes)

ABC 40030, 40031, 40032, 40034, 40053, 40107, 40126, 40127
Adelphia 40001
Allegro 40038
Antronix 40036, 40037
Apache 40124
Archer 40037, 40038, 40123
AT&T 40003
BBT 40129
Belcor 40125
Bell & Howell 40033
Bell South 40113
Cable Star 40125
Cable Vision 40005
Cabletenna 40036
Cableview 40035
Century 40038
Citizen 40038, 40118
Clearmaster 40112
ClearMax 40112
Colour Voice 40039
Comcast 40000, 40007
Comtronics 40040
Contec 40041
Coolmax 40112
COX 40000
Daeryung 40071
Digi 40117
Director 40007
Dumont 40117

Eastern 40042
Emerson 40123
Everquest 40040, 40108
Focus 40111
Garrard 40038
GC Electronics 40037, 40125
GE 40030, 40031
Gehua 40007
Gemini 40043, 40108, 40123
General Instrument 40007, 40031, 40105
GoldStar 40040, 40109
Goodmind 40123, 40124
Hamlin 40044, 40045
Hitachi 40031
Hytex 40126
Illico 40119
Jasco 40038, 40108
Jerrold 40007, 40031, 40043, 40053, 40067, 40105, 40108
LG 40116
Linsay 40132
Magnavox 40046
MegaCable 40007
Memorex 40047, 40107
Motorola 40000, 40003, 40007, 40072, 40105
Movie Time 40048
Multitech 40112
Multivision 40120
NEC 40033
NET Brazil 40070
Nexus 40124
Nova Vision 40121
Novaplex 40134
NSC 40048
Oak 40041, 40126
Pace 40006, 40110
Panasonic 40051, 40107
Panther 40117
Paragon 40107
Philips 40038, 40039, 40046
Pioneer 40002, 40049, 40071, 40109
Popular Mechanics 40111
Prelude 40124
Proscan 40030, 40031
Pulsar 40107
Quasar 40107
RadioShack 40108, 40112, 40123
RCA 40035
Realistic 40037
Recoton 40111
Regal 40045
Regency 40042
Rembrandt 40031
Rogers 40119
Runco 40107
Samsung 40006, 40040, 40049, 40069, 40109
Scientific Atlanta 40001, 40002, 40003, 40034, 40071, 40106
Signal 40040, 40043, 40108
Signature 40031
SL Marx 40040
Sony 40005, 40114
Standard Component 40050
Starcom 40043, 40053, 40108
Stargate 40040, 40043, 40108, 40123, 40124
Starquest 40043, 40108
StarSight 40131
Supercable 40105
Supermax 40112
Sylvania 40127
Tandy 40128
Telecaption 40130
TeleView 40040
Texscan 40127
TFC 40133
Time Warner 40004
Timeless 40040
Tocom 40032
Torx 40115
Toshiba 40107
Trans PX 40105
Tristar 40112
TS 40115
Tusa 40043, 40108
TV86 40048
US Electronics 40105
Unika 40036, 40037, 40038
United Artists 40126
United Cable 40053
Universal 40036, 40037, 40038, 40125
V2 40112
Videotron 40122
View Star 40041, 40046, 40048
Viewmaster 40112
ViewStar 40128
Vision 40112
Vortex View 40112
Zenith 40052, 40068, 40107, 40113
Zentek 4011

Satellite Receiver Codes

(Including Sat / PVR Boxes)

AccessHD 40096
Alpha Digital 40096
AlphaStar 40064
Apex Digital 40103
Artec 40092
CaptiveWorks 40088
Channel Master 40097
Chaparral 40056
Coolsat 40089
Coship 40093
Crossdigital 40146
Digital Stream 40102
DirecTV 40014, 40015, 40016, 40017, 40018, 40019, 40020, 40023, 40024, 40025, 40028, 40029, 40054, 40055, 40077, 40078, 40079, 40135, 40136, 40138, 40141
Dish Network System 40008, 40009, 40010, 40011, 40021, 40137, 40139, 40144
Dishpro 40137, 40139, 40144
Drake 40057
Echostar 40008, 40021, 40137, 40139, 40144, 40145
Expressvu 40139, 40144, 40145
GE 40012, 40013, 40098
General Instrument 40058, 40142
GOI 40144
Goodmind 40098
Hisense 40143
Hitachi 40029, 40065
HTS 40144
Hughes Network Systems 40016, 40018, 40019, 40023, 40025, 40054, 40135
Humax 40090
Ilo 40143

Insignia 40082
Jerrold 40142
JVC 40008, 40021, 40144
Lasonic 40099
LG 40082
Magnavox 40028, 40094
Memorex 40028
MicroGem 40100
Mitsubishi 40023, 40085
Motorola 40140, 40142
Next Level 40142
Panasonic 40017, 40083
Pansat 40086
Paysat 40028
PCT 40097
Philco 40094
Philips 40016, 40023, 40025, 40027, 40028, 40079, 40135
Pioneer 40016
Primestar 40063
Proscan 40012, 40013, 40138
Proton 40143
RadioShack 40142
RCA 40012, 40013, 40014, 40025, 40055, 40073, 40075, 40077, 40078, 40080, 40091
Realistic 40059
Samsung 40016, 40018, 40024, 40025, 40026, 40081
Sharp 40084
Sonicview 40101
Sony 40015, 40022, 40074, 40076, 40136
Star Choice 40140, 40142
STS 40066
STS1 40060
STS3 40061
STS4 40062
Tivax 40096
Tivo 40016, 40025
Toshiba 40019
UltimateTV 40136
Uniden 40028
US Digital 40143
Viewsat 40087
Voom 40142
Winegard 40104
Zenith 40020, 40082
Zentech 40095

PVR Codes

ABS 20410
Alienware 20410
AT&T 20245
Bang & Olufsen 20412
CyberPower 20410
Dell 20410
DirecTV 20238, 20240, 20241, 20243, 20405, 20406, 20409, 20411
Dish Network 20408
Dishpro 20408
Echostar 20408
Expressvu 20408
Gateway 20410
GOI 20408
Hewlett Packard 20410
Howard Computers 20410
HTS 20408
Hughes Network Systems 20240, 20238, 20241, 20243, 20407
Humax 20238
Hush 20410
iBUYPOWER 20410
JVC 20238, 20408
Linksys 20410
Media Center PC 20410
Microsoft 20410
Mind 20410
Niveus Media 20410
Northgate 20410
Panasonic 20245
Philips 20238, 20240, 20241, 20242, 20243, 20407
RCA 20238, 20243, 20407, 20409, 20411
ReplayTV 20244
Samsung 20241, 20243, 20407
Sonic Blue 20244
Sony 20239, 20410
Stack 20410
Systemax 20410
Tagar Systems 20410
Tivo 20238, 20239, 20240, 20242, 20243
Toshiba 20410
Touch 20410
UltimateTV 20411
Viewsonic 20410
Voodoo 20410
ZT Group 20410

Blu-Ray DVD Player Codes

Denon 20143, 20144
Insignia 20142
LG 20132
Marantz 20145, 20146
Panasonic 20128, 20129, 20130, 20197, 20198
Pioneer 20134, 20147
Samsung 20015, 20125
Sharp 20139, 20140, 20141
Sony 20005
Vizio 22000

DVD Player Codes

Accele Vision 20137
Accurian 20311
Advent 20288
Aiko 20348
Aiwa 20207
Akai 20161, 20282, 20317
Akishi 20349
Akustic 20348
Alco 20286
Allegro 20306
Alpine 20152
Amphion Media Works 20151, 20330
AMW 20151
Anam 20392
Aodeiong 20358
Apex 20024, 20025, 20026, 20027, 20085, 20111, 20300, 20301
Apple 20189
Arrgo 20307
Aspire 20209, 20290
Astar 20181
ATLM 20369
Audiovox 20106, 20116, 20286
Axion 20162
Bang & Olufsen 20302
Blaupunkt 20136, 20301
Blue Parade 20298
Bose 20076, 20086, 20393, 20394
BOSS 20138
Boston Acoustics 20331
Brand 20383

Broksonic 20007, 20282
Caixing 20389
California Audio Labs 20284
Cambridge Sound Works 20203
Caravell 20362
CAVS 20210
Changhong 20285, 20345
CineVision 20114, 20306
Clarion 20154
Classic 20131
Coby 20087, 20095, 20123, 20289
Conic 20370
Curtis 20095
Curtis Mathes 20308
CyberHome 20028, 20070, 20307, 20323, 20326
Cytron 20160
Daewoo 20093, 20306, 20317
Dayu 20388
DCS 20363
Denca 20367
Denon 20108, 20115, 20143, 20144, 20284
Desay 20185
Diamond Vision 20237
Dihe 20338
Ding Tian 20342
Disney 20090, 20096
Dual 20172
Durabrand 20309
DVD2000 20295
Dynex 20193
Eclipse 20126
Electrohome 20395
Emerson 20041, 20135, 20283, 20303, 20310
Enterprise 20303
ESA 20182, 20310
Fisher 20168, 20304
Funai 20310
Gateway 20327
GE 20082, 20296, 20301
Gewang 20361
GFM 20149
Giec 20355
Go Video 20306, 20327, 20396
GoldStar 20167
GPX 20112
Gradiente 20158, 20284
Greenhill 20301
Grundig 20297
Haier 20165, 20340
Haitai 20364
Haoji 20384
Harman/Kardon 20124, 20305
Hisense 20344
Hitachi 20013, 20232
Hiteker 20300
Huabao 20375
Huabaojamo 20334
iLive 20205
Ilo 20159
iLuv 20174
Initial 20159, 20301
Insignia 20142, 20150, 20164, 20202, 20310
Integra 20285, 20298
iSymphony 20190
Jamo 20206
JBL 20104, 20305
Jensen 20171, 20289, 20397
Jieke 20390
Jingewangpai 20375
Jingwei 20336
Jinwang 20377
Jugao 20359
JVC 20029, 20030, 20031, 20032, 20033, 20034, 20035, 20036, 20037, 20098, 20119, 20195, 20299
Jwin 20169, 20219
Kawasaki 20286
KEF 20398
Kennood 20386
Kenwood 20122, 20284
Ketai 20376
KLH 20286, 20301
Klipsch 20332
Konka 20316
Koss 20101, 20199, 20292
Lafayette 20351
Landel 20312
Lasonic 20155, 20220, 20399
Legend-V 20365
Lenoxx 20291, 20309
Lexicon20314
LG 20091, 20100, 20117, 20132, 20180, 20303, 20306
Linshuma 20378
Liquid Video 20292
LiteOn 20102, 20235, 20236, 20311, 20327
Loewe 20313, 20320
Longzhipai 20354
Magnavox 20081, 20142, 20283, 20294, 20297, 20310
Malata 20346
Marantz 20145, 20146, 20297
Maxview 20368
McIntosh 20211
Memorex 20090, 20282
Microsoft 20296
Mintek 20159, 20301
Mitsubishi 20092, 20295
Mitsui 20353
Mitzu 20348
NAD 20156, 20333
Nakamichi 20170, 20400
Napa 20350
Nesa 20301
Next Base 20312
NexxTech 20187
Niro 20401
Norcent 20095, 20221
Okon 20385
Onkyo 20099, 20110, 20285, 20294
Oppo 20163, 20188
Oritron 20101, 20292
Other Brand 20373
Pai Gao 20360
Panasonic 20016, 20017, 20018, 20019, 20020, 20021, 20022, 20023, 20073, 20075, 20080, 20118, 20128, 20129, 20130, 20197, 20198, 20222, 20229, 20230, 20232, 20233, 20284, 20294
Panda 20379
Parasound 20212
Philco 20286, 20351
Philips 20006, 20040, 20041, 20081, 20294, 20297, 20314
Pioneer 20042, 20043, 20044, 20045, 20134, 20147, 20234, 20298

Polaroid 20027, 20133, 20208, 20402
Polk Audio 20297
Portland 20317
Power Sound 20348
Prima 20192, 20403
Primas 20335
Princeton 20315
Proceed 20300
Proscan 20082, 20296
Protron 20213
Pye 20166
Qinghuatongfang 20382
Qisheng 20372
Qixing 20391
Qwestar 20101
RCA 20038, 20039, 20082, 20286, 20296, 20298, 20301
Regent 20291
Rio 20306
Rotel 20214, 20299
Rowa 20287
Royal 20351
Saba 20404
Sampo 20157, 20325, 20328
Samsung 20011, 20012, 20013, 20014, 20015, 20077, 20079, 20083, 20088, 20125, 20176, 20191, 20231, 20284
Sansui 20127, 20282
Sanyo 20200, 20282, 20304
Sast 20336
Sensory Science 20327
Shanshui 20374
Sharp 20120, 20139, 20140, 20141, 20204, 20328
Sharper Image 20323
Sherwood 20203, 20317
Shinco 20136
Shinsonic 20159, 20293
Shumaling 20337
Sigma Designs 20315
Skyworth 20375
Sonashi 20356
Sonic Blue 20306, 20396
Sonico 20352
Sony 20000, 20001, 20002, 20003, 20004, 20005, 20071, 20074, 20078, 20084, 20089, 20177, 20178, 20179, 20194, 20223, 20224, 20225, 20293
Sowa 20347
Spectroniq 20215
Sungale 20184
Superscan 20103, 20283
Supersonic 20351
SVA 20319
Sylvania 20041, 20103, 20148, 20149, 20283, 20310, 20329
Symphonic 20103, 20183
Tatung 20366
TCL 20371
Teac 20136, 20286
Technics 20284
Techwood 20153
Terapin 20321
Theta Digital 20298
Tianli 20343
Toshiba 20006, 20007, 20008, 20009, 20010, 20072, 20105, 20109, 20121, 20196, 20226, 20227, 20228, 20282, 20294
Tredex 20318
Trutech 20186, 20218
Tsinghuatongfang 20357
Tview 20173
Urban Concepts 20294
US Logic 20159
Venturer 20201, 20286
Victor 20380
Vizio 20322, 20324, 22000
Vocopro 20175, 20216
VocoStar 20217
Wanbao 20355
Wanyan 20346
Weifa 20381
Westinghouse 20113
Xbox 20296
Xianpai 20338
Xindai 20387
Yamaha 20016, 20107, 20284, 20297
YMT 20356
Youbishen 20341
Yuxing 20339
Zenith 20091, 20094, 20097, 20294, 20303, 20306

Amplifier / Receiver / Tuner Codes

Accurian 30164
ADA 30165
ADC 30133
Adcom 30104
Aiwa 30087, 30162, 30260
Alco 30139
Altec Lansing 30166
AMC 30167
Amphion Media Works 30140, 30145
Amplifier Technologies 30200
AMW 30140
Anam 30135, 30149
Antex 30168
Apex 30099
Apple 30169
Aragon 30201
Atlantic Technology 30170
Audio Access 30202
Audio Authority 30203
Audio Tron 30171
Audiophase 30204
AudioSource 30205
Audiotronic 30136
Audiovox 30098, 30139
B & K 30105
Bang & Olufsen 30144
Blaupunkt 30206
Bondstec 30207
Bose 30062, 30076, 30150, 30151, 30261
Boston Acoustics 30146
Cambridge Soundworks 30121
Capetronic 30133, 30208
Carver 30136, 30162
Casio 30209
Celestion 30210
Clarion 30211
Classic 30109
Clatronic 30212
Coby 30092, 30213, 30262
Compaq 30172
Creative 30173
Crown 30214
Curtis 30103, 30215
Curtis Mathes 30129

Daewoo 30216
DBX 30174
Dell 30217
Delphi 30218
Denon 30051, 30052, 30053, 30054, 30055, 30102
D-Link 30175
EAD 30219
Eclipse 30220
Elan 30176
Electrohome 30152
Emerson 30112, 30256
Farenheit 30221
Felston 30177
Fonmix 30163
Fosgate 30170
GE 30046, 30128
Go Video 30153
GPX 30100, 30257
Griffin 30178
Hanwah 30222
Harman/Kardon 30130, 30162
iHome 30263
iLive 30124
iLuv 30258
Imerge 30179
Inkel 30223
Insignia 30120
Insten 30180
Integra 30132
iPort 30181
iSymphony 30125, 30258
Jamo 30126
JBL 30097
Jensen 30154
Jerrold 30182
JVC 30031, 30032, 30033, 30034, 30035, 30259
Jwin 30265
KEF 30155
Kenwood 30036, 30037, 30038, 30039, 30040, 30065, 30071, 30077, 30137
KLH 30139
Klipsch 30147
Koss 30117, 30138
Krell 30110
Lasonic 30156
Left Coast 30130
Lexicon 30224
LG 30093, 30264
Ligitek 30183
Linn 30162
Luxman 30184
LXI 30225
Magnadyne 30226
Magnat 30227
Magnavox 30066, 30133, 30136, 30162
Magnum Dynalab 30228
Marantz 30106, 30130, 30136, 30162
Mark Levinson 30185
Matrix Audio 30229
MCE 30230
McIntosh 30111
Mediacom 30231
Memorex 30186
Meridian 30232
Micromega 30233
Mitsubishi 30096
Motorola 30234
Musical Fidelity 30235
NAD 30143, 30148
Nakamichi 30142, 30157
NEC 30131, 30236
Netgear 30187
Nikko 30237
Niles 30238
Niro 30158
Nubert 30188
Nuvo 30239
Olive 30189
Omnifi 30190
Onkyo 30041, 30042, 30043, 30044, 30045, 30067, 30069, 30070, 30075, 30080, 30091
Optimus 30129, 30133, 30134, 30135
Oritron 30138
Panasonic 30019, 30020, 30021, 30022, 30023, 30115, 30116, 30255
Parasound 30113
Penney 30240
Performance Teknique 30241
Philips 30094, 30130, 30136, 30162
Pioneer 30024, 30025, 30026, 30027, 30028, 30029, 30030, 30060, 30063, 30078, 30127, 30129, 30133, 30134
Polaroid 30159
Polk Audio 30107, 30130, 30162
Prima 30160
Primare 30242
Proscan 30046
RCA 30046, 30047, 30048, 30049, 30088, 30129, 30133, 30134, 30135, 30139
Revox 30243
Rio 30141
Roku 30191
Russound 30244
Saba 30161
Samsung 30073
Sangean 30245
Sansui 30162, 30246
Sanyo 30118
Sharp 30101, 30122, 30259
Sherwood 30089, 30123
Shure 30131
SII 30247
Sonic Blue 30141, 30153
Sony 30000, 30001, 30002, 30003, 30004, 30005, 30006, 30007, 30056 , 30057, 30058, 30059, 30061, 30064, 30074, 30077, 30082, 30083, 30084, 30085, 30086
Soundesign 30128
Soundmatters 30114
Soundstream 30248
Spatializer 30192
SpeakerCraft 30249
Stereophonics 30134
Sunfire 30137
SuperTech 30250
Teac 30135, 30139, 30258
Technics 30022, 30050
Techwood 30251
Teknika 30193
Thorens 30136
Tivoli Audio 30194
Topline 30252
Toshiba 30108
Universum 30253
Vector Research 30254
Velodyne 30195

Venturer 30119, 30139
Wards 30127, 30128, 30162
Xantech 30196
Xitel 30197
Yamaha 30008, 30009, 30010, 30011, 30012, 30013, 30014, 30015, 30016, 30017, 30018, 30068, 30072, 30079, 30081, 30095, 30132
Zektor 30198
Zenith 30090
Zon 30199

Audio Accessory Codes

(Including CD Players and Soundbars)

Acoustic Research 30294
ADC 30291
ADS 30295
Aiwa 30283
Akai 30292
ASI 33000
Audiophase 30282
Bose 30284
California Audio Labs 30296
Cambridge Audio 30297
Capetronic 30298
Carrera 30299
Carver 30300, 30331, 30332
Cary Audio Design 30301
CCE 30302
Clarion 30303
Classic 30304
Coby 30287
Cox Cable 33001
Creative 30305
DBX 30306
Denon 30267
Direct TV 33002
Dish Network 33003
DKK 30328
DMX Electronics 30331
Dynamic Bass 30332
Emerson 30279
Garrard 30307
Genexxa 30329
GPX 30280
Harman/Kardon 30273
Hitachi 30308
iHome 30288
iLuv 30286
Inkel 30309
iSymphony 30286
JVC 30269, 30281
Jwin 30290
Kenwood 30310, 30330
KLH 30311
Koss 30312
Krell 30331
LG 30289
Linn 30331
Luxman 30293
Magnavox 30313
Marantz 30314
Mark Levinson 30315
McIntosh 30316
Memorex 30317
Miro 30328
Mission 30331
Musical Fidelity 30318
NAD 30319
Nakamichi 30320
NEC 30321
Nikko 30322
NSM 30331
Onkyo 30268
Optimus 30328, 30329, 30332
Panasonic 30278
Philips 30275, 30276
Pioneer 30272
Polk Audio 30331
Proton 30331
QED 30331
Quad 30331
RCA 30266
Realistic 30332
Rotel 30331
SAE 30331
Samsung 30323
Sansui 30331
Sanyo 30324
SAST 30331
Sharp 30281
Sherwood 30325
Silsonic 30330
Sonic Frontiers 30331
Sony 30270, 30271, 30274
Super Atlas 33004
TAG McLaren 30331
Teac 30286
Technics 30277
Techwood 30326
Tivoli Audio 30327
Vizio 33005
Wards 30331
Yamaha 30285
Zonda 30331

VCR Codes

ABS 20410
Adventura 20050, 20250
Aiwa 20050, 20250
Akai 20061
Alienware 20410
American High 20249
Apex 20415
Asha 20054, 20247
Audio Dynamics 20058
Audiovox 20248, 20267
Beaumark 20054, 20247
Bell & Howell 20246
Broksonic 20279
Calix 20248
Candle 20247, 20248
Canon 20249
CineVision 20280
Citizen 20247, 20248, 20420
Colortyme 20058
Colt 20417
Craig 20054, 20247, 20248
Curtis Mathes 20058, 20247, 20249
Cybernex 20054, 20247
CyberPower 20410
Daewoo 20060, 20250, 20420
Davidson 20050
DBX 20058
Dell 20410
Denon 20055
DIRECTV 20407
Durabrand 20067
Dynatech 20050, 20250
Electrohome 20052, 20248
Electrophonic 20248
Emerson 20050, 20052, 20062, 20248, 20249, 20250, 20420
Fisher 20246

Fuji 20249
Funai 20050, 20062, 20250
Garrard 20050, 20250
Gateway 20410
GE 20054, 20247, 20249, 20418
Go Video 20054
GoldStar 20058, 20066, 20248, 20419
Gradiente 20050, 20250
Harley Davidson 20250
Harman/Kardon 20058
Headquarter 20246
Hewlett Packard20410
Hitachi 20050, 20055
Howard Computers 20410
Hughes Network Systems 20055, 20407
Humax 20407
Hush 20410
iBUYPOWER 20410
Instant Replay 20249
JC Penney 20058, 20246, 20247, 20248, 20249
JCL 20249
JVC 20056, 20057, 20058, 20246, 20254, 20264, 20265, 20266, 20268, 20269, 20270, 20271
Kenwood 20058, 20246
Kodak 20248, 20249
LG 20248
Linksys 20410
Lloyd's 20050, 20250
LXI 20248
Magnasonic 20062, 20420
Magnavox 20050, 20062, 20067, 20069, 20249
Magnin 20054, 20248, 20418
Marantz 20058, 20246, 20249
Marta20248
Matsushita 20249
Media Center PC 20410
MEI 20249
Memorex 20050, 20054, 20067, 20246, 20247, 20248, 20249, 20250, 20414, 20416, 20419
MGA 20052, 20054, 20418
MGN Technology 20054, 20247
Microsoft 20410
Mind 20410
Minolta 20055
Mitsubishi 20052, 20255
Motorola 20249
MTC 20050, 20054, 20247
Multitech 20050, 20247, 20250
NEC 20058, 20246
Nikko 20248
Niveus Media 20410
Noblex 20054, 20247
Northgate 20410
Olympus 20249
Optimus 20062, 20248, 20416
Optonica 20065
Orion 20258, 20414
Panasonic 20017, 20018, 20019, 20046, 20249, 20273, 20274, 20413, 20416
Penney 20054, 20055, 20418, 20419
Pentax 20055
Philco 20249
Philips 20065, 20249, 20256, 20278, 20407
Philips Magnavox 20256
Pilot 20248
Polaroid 20415
Profitronic 20054
Pulsar 20067
Pye 20281
Quarte 20246
Quartz 20246
Quasar 20249, 20416
RadioShack 20050, 20065, 20248, 20249, 20065, 20246, 20247, 20250
Radix 20248
Randex 20248
RCA 20053, 20054, 20055, 20247, 20249, 20252, 20275, 20276, 20418
Realistic 20050, 20065, 20246, 20247, 20248, 20249, 20250, 20065
ReplayTV 20413
Ricavision 20410
Runco 20067
Samsung 20054, 20059, 20060, 20061, 20247, 20263, 20277, 20407
Sankyo 20067
Sansui 20050, 20258, 20414
Sanyo 20054, 20246, 20247, 20418
Scott 20052, 20060
Sears 20050, 20055, 20246, 20248, 20249, 20419
Sharp 20064, 20065, 20257
Shogu20054, 20247
Singer 20249
Sonic Blue 20413
Sony 20047, 20048, 20049, 20050, 20251, 20253, 20260, 20261, 20262, 20272, 20410
Stack 20410
STS 20055, 20249
SuperScan 20063
Sylvania 20050, 20052, 20062, 20063, 20249, 20250
Symphonic 20050, 20062, 20063, 20250
Systemax 20410
Tagar Systems 20410
Tandy 20246
Tashiko 20248
Teac 20050, 20250
Technics 20249
Teknika 20050, 20248, 20249, 20250
Thomas 20050
Tivo 20407
TMK 20054, 20247
Toshiba 20051, 20052, 20060, 20259, 20410
Totevision20054, 20247, 20248
Touch 20410
Unitech 20054, 20247
Vector 20060
Vector Research 20058
Video Concepts 20058, 20060
Videosonic 20054, 20247
Viewsonic 20410
Villain 20050
Voodoo 20410
Wards 20050, 20054, 20055, 20065, 20247, 20248, 20249, 20250
XR-1000 20050, 20249, 20250
Yamaha 20058, 20246
Zenith 20050, 20066, 20067, 20068
ZT Group 20410

Chapter 10 Maintenance and Troubleshooting

Cleaning the TV and Remote Control

1. Remove the power adapter cable from the TV.
2. Use a soft cloth moistened with diluted neutral cleaner to clean the TV and remote control. VIZIO recommends using an HDTV cleaning solution which can be purchased at any major retailer.
3. Wring liquid out of the cloth before cleaning to prevent water from penetrating into the housing.
4. Wipe the TV and remote control with a dry cloth after cleaning.

Important:

- Do not use volatile solvent (such as toluene, rosin and alcohol). Such chemicals may damage the housing, screen glass, and remote control, and cause labeling to peel.
- The screen glass is very fragile. Do not scrape it with any sharp object.
- Do not press or tap the screen to avoid cracking.

Troubleshooting Guide

If the TV fails or the performance changes dramatically, check the following troubleshooting guide for possible solutions. Remember to check the peripherals to pinpoint the source of the failure. If the display still fails to perform as expected, contact the VIZIO for assistance by calling 1-877-MYVIZIO (698-4946) or e-mail us at techsupport@vizio.com.

General TV Problems	Solution
Receive the error message “No Signal.”	1. Press the INPUT button on the remote control to select a different input source. 2. If you are using cable connected directly to the TV or an antenna, scan for channels from the Tuner menu in the OSD. 3. Press the TV button on the top of the remote to return to the TV mode.
No power.	4. Make sure the power button is ON (VIZIO logo glows white). 5. Make sure the AC power cord is securely connected to the AC socket. 6. Plug another electrical device to the power outlet to verify that the outlet is working.
No sound.	• Press Volume + (Up) on the remote control. • Press MUTE on the remote control to make sure that MUTE is not ON. • Check your audio settings. The audio may be set to SAP, or the speakers are set to off. • Check the audio connections of external devices that may be connected to the HDTV. • If you are using an antenna, the signal strength of the channel may be low. Make sure your antenna is connected securely to the TV and move the antenna around the room or close to a window.
If the screen is black.	• Make sure the power button is ON (VIZIO Logo glows white). • Press the INPUT button on the remote control to select a different input source. • Check the connections of external devices that may be connected to the HDTV. • Press the TV button on the top of the remote to return to the TV mode.

General TV Problems	Solution
Power is ON but there is no image on the screen.	• Make sure all cables attached to the HDTV are connected to the correct output on the external device. • Adjust brightness, contrast or backlight. • Press the INPUT button on the remote control to select a different input source. • Press the TV button on the top of the remote to return to the TV mode.
Wrong or abnormal colors appear.	• Check Color and Tint settings in Picture Menu. • Reset Picture settings. • Check the video cables to make sure they are securely connected. • If you are using an antenna, the signal strength of the channel may be low. Make sure your antenna is connected securely to the TV and move the antenna around the room or close to a window.
Control buttons do not work.	• Press only one button at a time. • Press the TV button on the top of the remote to return to the TV mode.
Remote control does not work.	• Point the remote control directly at the remote sensor on your TV. • Remove any obstacles between the remote control and the remote sensor. • Replace dead batteries with new ones. • Press the TV button on the top of the remote to return to the TV mode.
There appear to be image quality issues.	• If you are using an antenna, the signal strength of the channel may be low. Make sure your antenna is connected securely to the TV and move the antenna around the room or close to a window. • For best image quality, view HD wide-screen programs where possible. • If HD content is not available view “Standard Definition” from a digital source. • Standard, analog TV will always be noticeably inferior to HD because your digital flat panel TV has video that is many times better than old TV so you will see interference and deficiencies you did not know you had.
You cannot see a picture.	• Make sure the power button is ON (VIZIO logo glows white). • Make sure the AC power cord is securely connected to the AC socket. • Press the INPUT button on the remote control to select a different input source. • Press the TV button on the top of the remote to return to the TV mode. • Check the connections of external devices that may be connected to the HDTV. • If your HDTV is connected to a computer, press any button on your keyboard to “wake” your computer. • If you are using an antenna, the signal strength of the channel may be low. Make sure your antenna is connected securely to the TV and move the antenna around the room or close to a window.
You see a distorted picture or hear unusual sound.	• You may be getting interference from electrical appliances, cars, motorcycles, or fluorescent lights. If you have not mounted it on the wall, try moving your HDTV to another location to see if this is the cause of the problem.
The picture has abnormal patterns.	• Check the connections of external devices that may be connected to the HDTV. • Make sure the specifications of external devices meet the specifications of your HDTV (like resolution). • If you are using an antenna, the signal strength of the channel may be low. Make sure your antenna is connected securely to the TV and move the antenna around the room or close to a window.

General TV Problems	Solution
The display image does not cover the entire screen.	• If you are in RGB mode (Computer), make sure that H-Size and V-Position in the On Screen Display (OSD) are set correctly. • If you are using TV, AV1, AV2 or Component with 480i input, press the WIDE button on the remote control to scroll through various screen modes.
You can see a picture but you cannot hear sound.	• Press Volume + (Up) on the remote control. • Press MUTE on the remote control to make sure that MUTE is not ON. • Check your audio settings. The audio may be set to SAP, or the speakers are set to off. • Check the audio connections of external devices that may be connected to the HDTV.
The TV has pixels (dots) that are always dark or colored.	• Your HDTV is manufactured using an extremely high level of precision technology, however, sometimes some pixels of your HDTV may not display. Pixel defects within industry specifications are inherent to this type of product and do not constitute a defective product.
You see “noise” or “trash” on the screen.	• When your HDTV’s digital capabilities exceed a digital broadcast signal, the signal is up-converted (increased) to match your TV’s display capabilities. Up-converting can cause noise or trash. • If you are using an antenna, the signal strength of the channel may be low. Make sure your antenna is connected securely to the TV and move the antenna around the room or close to a window.
You switch to a different input and the volume changes.	• The TV remembers the volume level from the last time you adjusted it. If the sound level is higher or lower from another source, then the volume will change.
You switch to a different input and the screen size changes.	• The TV remembers the viewing mode from the last time you used a particular input (AV-1, AV-2, Component, HDMI and TV).
Tips for High-Definition Users.	• Your HDTV is an ideal platform for viewing High Definition Content. • Best image quality will be achieved by HDMI. The next best is Component, followed by Composite. • Due to variances in broadcast practices, it is possible some image distortions can occur.
Tips for Letterbox Content Users.	• Some Letterboxed (or “Widescreen”) versions of DVD movies are formatted for standard 4:3 Televisions. Your HDTV has the ability to expand this content so the entire screen is filled at the expense of image accuracy. To use this function, press ZOOM on the remote control to cycle among the options.

Media Viewer Problems	Solution
USB device is not recognized.	• Make sure the device is correctly inserted. • Make sure the device is FAT or FAT32 • Make sure it contains the supported files.
Image or sound is interrupted or distorted.	• Make sure the device is correctly inserted. • Make sure that the file complies with the supported format, bit rate and/or profile. Also check the file for damage. • Some files that comply with the supported format may not play back or display properly.
Slideshow doesn’t start.	• Make sure the viewer isn’t in pause, rotation, or zoom mode.

Telephone & Technical Support

Products are often returned due to a technical problem rather than a defective product that may result in unnecessary shipping charges billed to you. Our trained support personnel can often resolve the problem over the phone. For more information on warranty service or repair, after the warranty period, contact our Support Department at the number below.

Customer support and quality service are integral parts of VIZIO's commitment to service excellence.

For technical assistance contact our VIZIO Technical Support Department via email or phone.

Email: **techsupport@VIZIO.com**

(877) 698-4946 Fax: (949) 585-9563

Hours of operation: Monday - Friday: 6 am to 9 pm

Saturday – Sunday: 8 am to 4 pm

Have your VIZIO model number, serial number, and date of purchase available before you call.

VIZIO

Address:

39 Tesla

Irvine, CA 92618, USA

Telephone: (888) 849-4623 (949) 428-2525 Fax: (949) 585-9514

Web: **www.VIZIO.com**

Compliance

Caution: Always use a power cable that is properly grounded. Use the AC cords listed below for each area.

USA: UL **Canada**: CSA

Germany: VDE **UK**: BASE/BS

Japan: Electric Appliance Control Act

FCC Class B Radio Interference Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

Notice:

1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables and AC AC/DC power adapter, if any, must be used in order to comply with the emission limits.
3. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. It is the responsibilities of the user to correct such interference.

Chapter 11 Specifications

Product specifications may change without notice or obligation.

M320NV	Specifications	
Panel	31.55” Diagonal, 16:9 Aspect Ratio	
Resolution	1920 x 1080 pixels	
Pixel (Dot) Pitch	0.363mm(H) x 0.363mm(V)	
Display Compatibility	1080P (FHDTV)	
Colors	16.7 million	
Brightness cd/m2 (typical)	450nits	
Contrast	1300:1	
Response Time	5ms (typical)	
Viewing Angle	178° (horizontal/vertical)	
Inputs	3 x HDMI with HDCP (2 back, 1 side) 1 x RF 1x Composite Video and Stereo Audio 1x Component YPbPr plus Stereo Audio 1x Computer RGB plus Stereo Audio 1x USB (side)	
Outputs	1x 5.1 S/PDIF Optical Digital Audio, 1x Stereo Audio	
Features	60 Hz E-LED panel, 1080P FHDTV, HDMI v1.3, 3D Comb Filter, Digital Audio Amplifier, Dolby Digital for ATSC/QAM, Signal Compatibility: 480I(SDTV), 480P(EDTV), 720P(HDTV), 1080I(HDTV), 1080P(FHDTV), Channel Skip/Add, VIDEO/INPUT Naming Capability, Closed Caption, Parental Control/V-CHIP 2.0, Programmable Timer, PIP/POP, SRS TSHD,SRS TruVolume ,HD Game Port, Noise Reduction, MTS Stereo Decoder, Dolby Digital for ATSC/QAM, VESA Mount Compatible, Multimedia(JPG only)	
Technical Features	ATSC/Clear QAM tuner, NTSC video decoding, 3:2 or 2:2 reverse pull-down, Motion adaptive de-interlace, Progressive video scan via Component/VGA/HDMI, FHDTV via HDMI or Component, Color temperature adjustments of 6500K/9300K/11000K, Independent Red/Green/Blue adjustments for color temperature fine tuning, Signal Compatibility 480i (SDTV), 480P (EDTV), 720P (HDTV), 1080i (HDTV), 1080P (FHDTV), Computer support at 640x480/800x600/1024x768/ 1920x1080 via VGA/HDMI	
Special Features	• Multimedia: support JPG only • Jag Wheel Key • HDMI CEC	• Light Sensor • Detachable Base
Speakers	2xBuilt-in, 10W Speakers	
Panel Life	30,000 hours to half the original brightness	
Power		
Input	IEC Connector for direct power line connection	
Voltage Range	100~240 Vac at 50/60Hz	
Power Consumption	57.1W (Avg), 0.29W standby	
Environmental Conditions		
Dimensions	31.63” W x 21.96” H x 7.87” D with stand; 31.63” W x 20.07” H x 1.69” D without stand	

M320NV	Specifications
	803.4 x 558 x 200mm with stand; 803.4 x 510 x 43mm without stand
Net Weight	21.61 lbs without stand; 23.81 lbs with stand 9.8 kg without stand; 10.8 kg with stand
Gross Weight	30.42 lbs; 13.8 kg
Certifications	CSA, CSA-US, FCC Class B
Compliances	Energy Star 4.0. ATSC Spec A/65, EIA/CEA-766-A

M370NV	Specifications
Panel	37” Diagonal, 16:9 Aspect Ratio
Resolution	1920 x 1080 pixels
Pixel (Dot) Pitch	0.426mm(H) x 0.426mm(V)
Display Compatibility	1080P (FHDTV)
Colors	16.7 million
Brightness cd/m2 (typical)	450nits
Contrast	1400:1
Response Time	5ms (typical)
Viewing Angle	178° (horizontal/vertical)
Inputs	3 x HDMI with HDCP (2 back, 1 side) 1 x RF 1x Composite Video and Stereo Audio 1x Component YPbPr plus Stereo Audio 1x Computer RGB plus Stereo Audio 1x USB (side)
Outputs	1x 5.1 S/PDIF Optical Digital Audio, 1x Stereo Audio
Features	60 Hz E-LED panel, 1080P FHDTV, HDMI v1.3, 3D Comb Filter, Digital Audio Amplifier, Dolby Digital for ATSC/QAM, Signal Compatibility: 480I(SDTV), 480P(EDTV), 720P(HDTV), 1080I(HDTV), 1080P(FHDTV), Channel Skip/Add, VIDEO/INPUT Naming Capability, Closed Caption, Parental Control/V-CHIP 2.0, Programmable Timer, PIP/POP, SRS TSHD,SRS TruVolume ,HD Game Port, Noise Reduction, MTS Stereo Decoder, Dolby Digital for ATSC/QAM, VESA Mount Compatible, Multimedia(JPG only)
Technical Features	ATSC/Clear QAM tuner, NTSC video decoding, 3:2 or 2:2 reverse pull-down, Motion adaptive de-interlace, Progressive video scan via Component/VGA/HDMI, FHDTV via HDMI or Component, Color temperature adjustments of 6500K/9300K/11000K, Independent Red/Green/Blue adjustments for color temperature fine tuning, Signal Compatibility 480i (SDTV), 480P (EDTV), 720P (HDTV), 1080i (HDTV), 1080P (FHDTV), Computer support at 640x480/800x600/1024x768/ 1920x1080 via VGA/HDMI
Special Features	• Multimedia: support JPG only • Jag Wheel Key • HDMI CEC • Light Sensor • Detachable Base
Speakers	2xBuilt-in, 10W Speakers
Panel Life	30,000 hours to half the original brightness

M370NV	Specifications
Power	
Input	IEC Connector for direct power line connection
Voltage Range	100~240 Vac at 50/60Hz
Power Consumption	56W (Avg), 0.29W standby
Environmental Conditions	
Dimensions	36.39” W x 24.58” H x 8.26” D with stand; 36.39” W x 22.75” H x 1.69” D without stand 924 x 624 x 210mm with stand; 924 x 578 x 43mm without stand
Net Weight	26.59 lbs without stand; 29.23 lbs with stand 12.06 kg without stand; 13.26 kg with stand
Gross Weight	35.94 lbs; 16.3 kg
Certifications	CSA, CSA-US, FCC Class B
Compliances	Energy Star 4.0. ATSC Spec A/65, EIA/CEA-766-A

Note: The Federal Communications Commission (FCC), the Consumer Electronics Association (CEA) and the Consumer Electronics Retailers Coalition (CERC) have made a new tip sheet available for digital television (DTV) retailers to reproduce and distribute to consumers on the sales floor. The file may be downloaded online at www.dtv.gov. While you’re there, check out the other useful information in the FCC is making available to consumers interested in learning more about the analog to digital transition.

Preset PC Resolutions

If connecting to a PC through the RGB PC input, set the TV timing mode to VESA 1920x1080 at 60Hz for best picture quality (refer to the graphic card's user guide for questions on how to set this timing mode). See the table below for the factory preset resolutions.

Mode No.	Resolution	Refresh Rate (Hz)	Horizontal Frequency (KHz)	Vertical Frequency (Hz)	Horizontal Sync Polarity (TTL)	Vertical Sync Polarity (TTL)	Pixel Rate (MHz)	Remark
1	640 x 480	60	31.469	59.941	N	N	25.175	Windows
2	640 x 480	75	37.500	75.000	N	N	31.500	Windows
3	800 x 600	60	37.879	60.317	P	P	40.000	Windows
4	800 x 600	72	48.077	72.188	P	P	50.000	Windows
5	800 x 600	75	46.875	75.000	P	P	49.500	Windows
6	1024 x 768	60	48.363	60.004	N	N	65.000	Windows
7	1024 x 768	70	56.476	70.069	N	N	75.000	Windows
8	1024 x 768	75	60.023	75.029	P	P	78.750	Windows
9	720 x 400	70	31.469	70.087	N	P	28.322	DOS
10	◎1920 x 1080	60	66.587	59.934	P	N	138.50	Windows

Note: P: positive, N: negative, ◎: Primary mode

Resolution through RGB Input

If your PC supports VESA Reduce Blanking timing via the VGA card drive program (usually offered by the VGA Card Manufacturer), your TV set is equipped to have the 1920x1080 resolution display through this connection using the following timing 138.5MHz. The following parameters are often the values required by the software or programs to set up the display:

Parameters	Horizontal Values (Pixels)	Vertical Values (Lines)
Address	1920	1080
Front Porch	48	3
Sync Width	32	5
Back Porch	80	23
Total	2080	1111
Frequency	66.587 KHz	59.934 Hz
Sync Polarity	P	N
Pixel Rate (MHz)	138.5	
Refresh Rate (Hz)	60	

Warranty

ONE-YEAR LIMITED WARRANTY ON PARTS AND LABOR

(Covers units purchased as new in United States and Puerto Rico Only)

VIZIO provides a warranty to the original purchaser of its products against defects in materials and workmanship for a period of one year of non-commercial usage and ninety (90) days of commercial use. If a VIZIO product is defective within the warranty period, VIZIO will either repair or replace the unit at its sole option and discretion.

To obtain warranty service, contact VIZIO Technical Support via email: TechSupport@VIZIO.com or via phone at 877 MY VIZIO (877.698.4946) from 6:00AM to 9:00PM Monday through Friday and 8:00AM to 4:00PM Saturday and Sunday, Pacific Time, or visit www.VIZIO.com. Proof of purchase in the form of a purchase receipt or copy thereof is required.

Parts and Labor

There will be no charge for parts or labor during the warranty period. Replacement parts and units may be new or recertified at VIZIO's option and sole discretion. Replacement parts and units are warranted for the remaining portion of the original warranty or for ninety (90) days from warranty service or replacement, whichever is later.

Types of Service

Units 30" or larger will usually be serviced in-home. In-home service requires complete and easy access to the unit and does not include de-installation or re-installation of the product. However, in some cases, it may be necessary to send the unit to a VIZIO service center. VIZIO will cover the transportation charges to and from the same customer location.

Units less than 30" must be sent to a VIZIO service center. VIZIO is not responsible for transportation costs to the service center, but VIZIO will cover return shipping to the customer. PRE-AUTHORIZATION IS REQUIRED BEFORE SENDING ANY UNIT IN FOR SERVICE.

Any returns to VIZIO's service centers must utilize either the original carton box and shipping material or a replacement box and material provided by VIZIO. VIZIO technical support will provide instructions for packing and shipping the unit to the VIZIO service center.

Limitations and Exclusions

VIZIO's one-year limited warranty only covers defects in materials and workmanship. Items not covered include but are not limited to cosmetic damage, normal wear and tear, misuse, signal issues, power surges, and damages from shipping, acts of God, any sort of customer misuse, installation, customer modifications, adjustments, and set-up issues. Units with unreadable or removed serial numbers, "image burn-in", and routine maintenance are not covered. This warranty does not cover products sold "AS IS", "FACTORY RECERTIFIED", or by a non-authorized reseller.

THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE LISTED OR DESCRIBED ABOVE. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE PERIOD OF TIME SET FORTH ABOVE. VIZIO'S TOTAL LIABILITY FOR ANY AND ALL LOSSES AND DAMAGES RESULTING FROM ANY CAUSE WHATSOEVER SHALL IN NO EVENT EXCEED THE PURCHASE PRICE OF THE DISPLAY. VIZIO SHALL NOT BE RESPONSIBLE FOR LOSS OF USE, COMMERCIAL LOSS, LOST REVENUE OR LOST PROFITS, OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE. THIS WARRANTY IS SUBJECT TO CHANGE WITHOUT NOTICE. CHECK www.VIZIO.com FOR THE MOST CURRENT VERSION.

Personal Data

If your VIZIO product is capable of storing personal data and other information, **ALL CONTENTS AND INFORMATION WILL BE DELETED IN THE COURSE OF SOME IN-HOME AND ALL SHIP-IN WARANTY SERVICE.** If this occurs, your product will be restored to you configured **as originally purchased**. **You will be responsible for restoring all applicable data and passwords.** Recovery and reinstallation of user data is not covered under this Limited Warranty. **In order to protect your personal information, VIZIO recommends that you always clear all personal information from the unit before it is serviced, regardless of the servicer.**

ZERO BRIGHT PIXEL DEFECT GUARANTEE

This policy covers "zero bright pixel" defects for the duration of the limited "ONE YEAR WARRANTY" on select new product purchases. To determine if this guarantee applies to your product, refer to the "DETAILS" tab of the model's product information page (www.VIZIO.com) or look for the "zero bright pixel" guarantee on the box.

Index

16:9 30
4:3 30
Accessories 9
Adjustments
  Advanced 29
Advanced Adjustments 29
Ambient Light Sensor 33
Antenna 19
Aspect Ratio 30
Audio Menu
  Advanced Audio 34
  Analog Audio Out adjustments 34
  Audio Mode adjustments 34
  Balance adjustments 34
  Digital Audio Out 34
  Equalizer adjustments 35
  Lip Sync adjustments 34
  Reset Audio Mode 35
  Speaker adjustments 34
  SRS TruVolume 34
  SRS TSHD (surround sound) adjustments 34
AV connector 19
Blackbars 30
Blocking Channels 37
Brightness 32
Cable Box
  Connecting 20
CC Closed Caption 31
CEC 39
Cleaning 58
Coaxial connection
  Satellite box 24
Coaxial Connection
  Cable TV 24
Color 32
Component Connector 19
Composite Connector 19
Computer
  Connecting 26
  Preset Resolutions 65
  Resolution through RGB 65
Connecting
  Computer 26
  RGB 26
  VGA 26
Connecting Equipment
  Cable 20
  DVD 22
  Home Theater 25
  Rear Panel Connections 13
  Satellite Box 20
  Sound system 25
  VCR 24
  Video Camera 24
Contents 9
Contrast 32
Controls
  Front Panel 12
  Jag Wheel 12
Daylight Savings setting 39
DTV Transition 5
DVD Player
  Connecting 22
DVI
  Cable Box 20
  Satellite Box 20
EPG 18
Getting Started 16
Grounding 4
GUIDE Button 18
HDMI 19
HDTV Location 10
Help Menu
  Reset All Settings 41
  Setup Wizard 41
  System Info 41
Help Menu 41
Home Theater
  Connecting 25
Horizontal/Vertical Position adjustments 32
Input Source
  Choosing 17
Inputs
  Antenna 4
  Connectors 19
Jag Wheel 12
Maintenance of TV 58
Media Menu
  Duration 28, 40
  Info 28, 40
  Repeat 28, 40
  Slideshow 28, 40
  Slideshow Effect 28, 40
  Sort By 28, 40
  Thumbnail Size 28, 40
Media Menu 40
Menu Language 39
Name Input 36
OSD 29
  CC Menu 31
  Help Menu 41
  Input Menu 29
  Media Menu 40
  Picture Menu 31
  Settings Menu 35
  Sleep Timer Menu 31
  Wide Menu 30
Parental Controls
  Alt Rating Region 38
  Block Unrated TV 38
  Canadian English Rating 38
  Canadian French Rating 38
  Change the Password 39
  Channel Block 37
  Reset Locks 39
  USA Movie Rating 38

- USA TV Rating....37
Parental Controls....37
Password....39
Photos
- Adjusting Settings....28
- Viewing....27
Picture
- Reset Picture Mode....33
Picture Menu....31
- Adaptive Luma....33
- Advanced Video....33
- Ambient Light Sensor....33
- Backlight....31
- Backlight Control....33
- Brightness....32
- Color....32
- Color Enhancement....33
- Color Temperature....33
- Contrast....32
- Film Mode....33
- Noise Reduction....33
- Picture Mode....31
- Sharpness....32
- Tint....32

Pictures
- Adjusting Settings....28
- Create Slideshow....28, 40
- Info....28, 40
- Sort....28, 40
- Thumbnail Size....28, 40
- Viewing....27

Remote
- Programming Satellite Box....43

Remote Control....14
- Batteries....14
- Buttons....15
- Codes....43
- Precautions....14
- Programming....42
- Programming Cable Box....43
- Programming DVD Player....42
- Programming Home Theater System....42
- Range....14

RGB....19
Safety Instructions....2
Satellite Box
- Connecting....20

Search for channels....35
Setting Up....10
Settings Menu
- Audio....34, 36
- CEC....39
- Menu Language....39
- Parental Controls Menu....37
- Time & Local Settings....39
- Tuner....35

Setup Wizard....16
Sharpness....32
Skip Channel....36
Slideshow
- Duration....28, 40
- Effect....28, 40
- Mode....28, 40
- Repeat....28, 40

Specifications....62
Technical Support....61
Time Zone setting....39
Tint....32
Troubleshooting....58
Tuner Menu
- Analog MTS....36
- Auto Search....35
- Skip Channel....36
- Tuner Mode....35

TV Menu....29
- Partial Channel Search....35

TV Stand
- Attaching....10

USB Port....27
VCR
- Connecting....24

Video Camera
- Connecting....24

Wall mounting....11
Warranty....66
Watching TV
- Getting your Programs....17
- Program Information....18

Wide....30
Wizard....41